



User Guide

© Copyright 2013 Hewlett-Packard
Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by Hewlett-Packard Company under license. Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation. SD Logo is a trademark of its proprietor.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: July 2013

Document Part Number: 730501-001

Product notice

This guide describes features that are common to most models. Some features may not be available on your computer.

Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a refund subject to the refund policy of your place of purchase.

For any further information or to request a full refund of the computer, please contact your local point of sale (the seller).

Table of contents

1 Starting right	1
Best practices	1
Fun things to do	2
More HP resources	3
2 Getting to know your computer	5
Finding your hardware and software information	5
Locating hardware	5
Locating software	5
Front	6
Right side	7
Left side	9
Top	11
Bottom	12
Labels	13
Identifying the labels	13
3 Connecting to a network	14
Connecting to a wireless network	14
Using the wireless controls	14
Using an Internet service provider	14
Setting up a WLAN	15
Configuring a wireless router	15
Protecting your WLAN	15
Connecting to a WLAN	16
Connecting to a wired network	17
Connecting to a local area network (LAN)	17
4 Enjoying entertainment features	18
Using the webcam	19
Using audio	19

Adjusting the volume	19
Connecting speakers	19
Connecting headphones	20
Using Beats Audio	20
Accessing Beats Audio	20
Using video	20
Connecting an HDMI device	20
Using HDMI audio	21
Managing your audio and video files	21
Share media and data across your home group network (select models only)	22
Enable media sharing and set up a home group network	22
Stream and share media between mobile devices	22
Migrate or synchronize data	23
Share photos, videos, and music to and from your phone	23
Determining your Android phone operating system (OS) version	23
Download the sMedio TrueLink+ app to your phone	23
Start sharing media	23
5 Navigating using the keyboard and pointing devices	25
Using touch screen gestures	26
One-finger slide	26
Tapping	26
Scrolling	27
Pinching/stretching	27
Rotating (select models only)	28
Edge swipes	29
Right-edge swipe	29
Left-edge swipe	29
Top-edge swipe and bottom-edge swipe	30
Using the keyboard	31
Using the action keys	32
Using Microsoft Windows 8 shortcut keys	33
Using the integrated numeric keypad	33
6 Managing power	35
Initiating Sleep and Hibernation	35
Manually initiating and exiting Sleep	35
Manually initiating and exiting Hibernation	36
Setting password protection on wakeup	36
Shutting down (turning off) the computer	36

7 Managing and sharing information	38
Using a USB device	38
Connecting a USB device	39
Removing a USB device	39
Inserting and removing a memory card	40
8 Maintaining peak performance	41
Performing routine maintenance	41
Using Disk Cleanup	41
Using Disk Defragmenter	41
Updating programs and drivers	41
Cleaning your computer	43
Cleaning procedures	43
Cleaning the display (All-in-Ones or Notebooks)	43
Cleaning the sides or cover	43
Cleaning the keyboard or mouse	44
Using security measures	45
Setting Windows passwords	45
Setting Computer Setup (BIOS) passwords	46
Using Internet security software	46
Installing software updates	47
Installing Windows updates	47
Updating software	47
9 Using Computer Setup (BIOS) and HP PC Hardware Diagnostics (UEFI)	48
Starting Computer Setup (BIOS)	48
Updating the BIOS	48
Determining the BIOS version	48
Downloading a BIOS update	49
Using HP PC Hardware Diagnostics (UEFI)	50
Downloading HP PC Hardware Diagnostics (UEFI) to a USB device	50
10 Backing up, restoring, and recovering	51
Creating recovery media and backups	52
Creating HP Recovery media	52
Restore and recovery	54
Using Windows Refresh for quick and easy recovery	55
Remove everything and reinstall Windows	55
Recovering using HP Recovery Manager	56
What you need to know	56

Using the HP Recovery partition (select models only)	57
Using HP Recovery media to recover	57
Changing the computer boot order	57
Removing the HP Recovery partition	58
11 Troubleshooting	59
Wireless connection problems	59
Cannot connect to a WLAN	59
Cannot connect to a preferred network	59
Current network security codes are unavailable	60
Cannot connect to the wireless router	60
Network status icon is not displayed	61
Power problems	62
Computer will not turn on or start	62
Hard drive error	62
Computer is not responding	62
Computer shuts down unexpectedly	62
Computer Setup problems	63
The computer will not enter Computer Setup	63
Display problems	64
The display is blank	64
Images on the screen are too large or too small, or the images are fuzzy	64
Keyboard and mouse problems	65
Audio problems	67
No sound is produced	67
Software problems	68
12 Specifications	69
Operating specifications	69
13 Electrostatic Discharge	70
Index	71

1 Starting right

This computer is a powerful tool designed to enhance your work and entertainment. To get the most out of your computer, read this chapter to learn about best practices after setup, fun things to do with your computer, and where to get more HP resources.

Best practices

After you set up and register the computer, we recommend the following steps:

- If you haven't already done so, connect to a wired or wireless network. See details in [Connecting to a network on page 14](#).
- Become familiar with the computer hardware and software. For information, go to [Getting to know your computer on page 5](#) and [Enjoying entertainment features on page 18](#).
- Back up your hard drive by creating a recovery drive. See [Backing up, restoring, and recovering on page 51](#).

Fun things to do

- You know that you can watch a YouTube video on the computer. But did you know that you can also connect your computer to a digital set-top box or gaming console? For more information, see [Connecting an HDMI device on page 20](#).
- You know you can listen to music on the computer. But did you know that you can also stream live radio to the computer and listen to music or talk radio from all over the world? See [Using audio on page 19](#).
- Experience music the way the artist intended, with deep controlled bass and clear, pure sound. See [Using Beats Audio on page 20](#).
- Use the new Windows 8 touch gestures for smooth control of images and pages of text. See [Using touch screen gestures on page 26](#).

More HP resources

You have already used *Setup Instructions* to turn on the computer and locate this guide. To locate resources that provide product details, how-to information, and more, use this table.

Resource	Contents
<i>Setup Instructions</i>	Overview of computer setup and features.
<i>Windows 8 Basics</i> guide	Overview of using Windows® 8.
Help and Support	A broad range of how-to information and troubleshooting tips. From the Start screen, type h, and then select Help and Support. For U.S. support, go to http://www.hp.com/go/contactHP. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.
Instructional videos	How-to videos about using the features of your computer. Go to http://www.hp.com/supportvideos (English only)
<i>Upgrading and Servicing Guide</i>	Instructions for upgrading or replacing components of your computer. For U.S. support, go to http://www.hp.com/go/contactHP. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.
Troubleshooting	- Solutions to the following problems: - Wireless connection problems - Power problems - Display problems - Keyboard and mouse problems - Audio problems - Software problems See Troubleshooting on page 59 in this guide for more information.
<i>Safety & Comfort Guide</i>	- Proper workstation setup. - Guidelines for posture and work habits that increase your comfort and decrease your risk of injury. - Electrical and mechanical safety information.
Worldwide support web page	- Access to the following support options: - Online chat with an HP technician. - Email support. - Support telephone numbers. - HP service center locations. To get support in your language, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.
<i>Regulatory, Safety and Environmental Notices</i>	Important regulatory notices. To access this guide, select the HP Support Assistant app on the Start screen, select My computer, and then select User guides.

Resource	Contents
<i>Limited Warranty*</i> To access this guide, select the HP Support Assistant app on the Start screen, select My computer, and then select Warranty and services, or go to http://www.hp.com/go/orderdocuments.	• Specific warranty information about this computer.
*You can find the expressly provided HP Limited Warranty applicable to your product located with the user guides on your computer and/or on the CD/DVD provided in the box. In some countries/regions, HP may provide a printed HP Limited Warranty in the box. For countries/regions where the warranty is not provided in printed format, you may request a printed copy from http://www.hp.com/go/orderdocuments or write to: • North America: Hewlett-Packard, MS POD, 11311 Chinden Blvd., Boise, ID 83714, USA • Europe, Middle East, Africa: Hewlett-Packard, POD, Via G. Di Vittorio, 9, 20063, Cernusco s/Naviglio (MI), Italy • Asia Pacific: Hewlett-Packard, POD, P.O. Box 200, Alexandra Post Office, Singapore 911507 When you request a printed copy of your warranty, please include your product number, warranty period (found on your service label), name, and postal address. IMPORTANT: Do NOT return your HP product to the addresses above. For U.S. support, go to http://www.hp.com/go/contactHP. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.	

2 Getting to know your computer

Finding your hardware and software information

Locating hardware

To find out what hardware is installed on your computer:

1. From the Start screen, type **c**, and then select **Control Panel**.
2. Select **System and Security**, and then in the System area, click **Device Manager**.

A list displays all the devices installed on your computer.

Locating software

To find out what software is installed on your computer:


1. From the Start screen, right-click using the external wireless mouse.

– or –

Swipe down from the top edge of the computer screen.

2. Select the **All apps** icon.

Front



Component		Description
(1)	WLAN antennas (2)*	Send and receive wireless signals.
(2)	Internal microphones (2)	Record audio, automatically filtering out the noise around you.
(3)	Webcam light	On: The webcam is on.
(4)	Webcam	Records video and takes still photographs. To use the webcam, from the Start screen, type c , and then select Camera .
(5)	Speakers (2)	Produce sound.

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions. For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region. These notices are located in Help and Support.

Right side



Component		Description
(1)	 USB 3.0 port	Connects an optional USB 1.0, USB 2.0, or USB 3.0 device and provides enhanced USB power performance for USB 3.0 devices.
(2)	 USB 3.0 charging (powered) port	Connects an optional USB 1.0, USB 2.0, or USB 3.0 device. USB charging ports allow you to charge connected USB devices. Standard USB ports will not charge all USB devices or will charge using a low current. Some USB devices require power and require you to use a powered port. NOTE: USB charging ports can also charge select models of cell phones and MP3 players, even when the computer is off.

Component		Description
(3)	Subwoofer connector	Connects HP Pulse Subwoofer (purchased separately). The subwoofer provides superior bass sound.
(4)	 USB 2.0 ports (2)	Connect optional USB devices.
(5)	 RJ-45 (network) jack	Connects a network cable.
(6)	 Hard drive light	Blinking: The hard drive is being used.


Left side



Component			Description
(1)	HDMI	HDMI-in port	Connects an optional video or audio device, such as a gaming console or digital set-top box.

Component	Description
(2)  Audio-out (headphone) jack/ Audio-in (microphone) jack	Connects optional powered stereo speakers, headphones, earbuds, or a headset. Also connects an optional headset microphone. This jack does not support optional microphone-only devices. WARNING! To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, see the <i>Regulatory, Safety, and Environmental Notices</i>. NOTE: When a device is connected to the jack, the computer speakers are disabled.
(3)  Security cable slot	Attaches an optional security cable to the computer. NOTE: The security cable may not prevent the computer from being mishandled or stolen.
(4) AC adapter light	- On: The AC adapter is connected and the battery is charged. - Off: The computer is using battery power.
(5)  Power connector	Connects an AC adapter.

Top



Component		Description
(1)	Near Field Communication (NFC) antenna (select models only)	Sends and receives wireless signals to share media from your phone to your computer. For more information, see Start sharing media on page 23.
(2)	Power button	• When the computer is off, press the button to turn on the computer. • When the computer is in the Sleep state, press the button briefly to exit Sleep. • When the computer is in Hibernation, press the button briefly to exit Hibernation. CAUTION: Pressing and holding down the power button will result in the loss of unsaved information. If the computer has stopped responding and Microsoft® Windows® shutdown procedures are ineffective, press and hold the power button down for at least 5 seconds to turn off the computer. To learn more about your power settings, from the Start screen, type <code>p</code>. In the search box, type <code>power</code>, select Settings, and then select Power options.

Bottom



Component		Description
(1)	HDMI-in button	Switches the computer screen to the HDMI device. NOTE: The HDMI cable must be connected to the computer.
(2)	Memory card reader	Reads data from and writes data to memory cards such as Secure Digital (SD) memory cards.

Labels

Identifying the labels

The labels affixed to the computer provide information you may need when you troubleshoot system problems or travel internationally with the computer. The labels are located on the bottom of the computer stand.

- Service label—Provides important information to identify your computer. When contacting support, you will probably be asked for the serial number, and possibly for the product number or the model number. Locate these numbers before you contact support.
- Regulatory label(s)—Provide(s) regulatory information about the computer.
- Wireless certification label(s)—Provide(s) information about optional wireless devices and the approval markings for the countries or regions in which the devices have been approved for use.

3 Connecting to a network

You can explore the globe and access information from millions of websites using your computer and a wired or wireless network connection. This chapter will help you get connected to that world.

Connecting to a wireless network

Wireless technology transfers information across radio waves instead of wires. Your computer may be equipped with one or more of the following wireless devices:

- Wireless local area network (WLAN) device—Connects the computer to wireless local area networks. In a WLAN, the mobile wireless device in your computer communicates with a wireless router or a wireless access point.
- Bluetooth® device—Creates a personal area network (PAN) to connect to other Bluetooth-enabled devices such as computers, phones, printers, headsets, speakers, and cameras. In a PAN, each device communicates directly with other devices, and devices must be relatively close together.

For more information about wireless technology, see the information and website links provided in Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Using the wireless controls

The Network and Sharing Center allows you to set up a connection or network, connect to a network, and diagnose and repair network problems.

To use the Network and Sharing Center:

1. From the Start screen, type **c**, and then select **Control Panel**.
2. Select **Network and Internet**, and then select **Network and Sharing Center**.

For more information, go to Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Using an Internet service provider

When you are setting up Internet access in your home, you must establish an account with an Internet service provider (ISP). To purchase Internet service and a modem, contact a local ISP. The ISP will help set up the modem, install a network cable to connect your wireless router to the modem, and test the Internet service.



NOTE: Your ISP will give you a user ID and a password to use for Internet access. Record this information and store it in a safe place.

Setting up a WLAN

To set up a WLAN and connect to the Internet, you need the following equipment:


- A broadband modem (either DSL or cable) **(1)** and high-speed Internet service purchased from an Internet service provider
- A wireless router **(2)** (purchased separately)



NOTE: Some modems have a built-in wireless router. Check with your ISP to determine what type of modem you have.

- A wireless computer **(3)**

The illustration below shows an example of a wireless network installation that is connected to the Internet.



Additional wireless and wired computers can be connected to increase the size of your home network.

For help in setting up your WLAN, see the information provided by your router manufacturer or your ISP.

Configuring a wireless router

For help configuring a wireless router, see the information provided by your router manufacturer or your ISP.



NOTE: It is recommended that you initially connect your new wireless computer to the router by using the network cable provided with the router. When the computer successfully connects to the Internet, disconnect the cable, and access the Internet through your wireless network.

Protecting your WLAN

When you set up a WLAN or connect to an existing WLAN, always enable security features to protect your network from unauthorized access.

Wireless radio signals travel outside the network, so other WLAN devices can pick up unprotected signals. Take the following precautions to protect your WLAN:

- Use a firewall.

A firewall checks information and requests that are sent to your network. It then discards any suspicious items. Firewalls are available in both software and hardware. Some networks use a combination of both types.

- Use wireless encryption.

Wireless encryption uses security settings to encrypt and decrypt information that is transmitted over the network. For more information, go to Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Connecting to a WLAN

To connect to a WLAN, follow these steps:

1. Be sure that the WLAN device in your computer is on.
2. From the Start screen, point to the far-right upper or lower corner of the screen to display the charms.
3. Select **Settings**, and then click the network status icon.
4. Select a WLAN from the list.
5. Click **Connect**.

If the WLAN is a security-enabled WLAN, you are prompted to enter a security code. Type the code, and then click **OK** to complete the connection.

 **NOTE:** If no WLANs are listed, you may be out of range of a wireless router or access point.

 **NOTE:** If you do not see the WLAN you want to connect to, from the Windows desktop, right-click the network status icon, and then select **Open Network and Sharing Center**. Click **Set up a new connection or network**. A list of options is displayed, allowing you to manually search for and connect to a network or to create a new network connection.

After the connection is made, place the pointer over the network status icon in the notification area, at the far right of the taskbar, to verify the name and status of the connection.

 **NOTE:** The functional range (how far the wireless signals travel) depends on WLAN implementation, router manufacturer, and interference from other electronic devices or structural barriers such as walls and floors.

Connecting to a wired network

⚠ WARNING! To reduce the risk of electric shock, fire, or damage to the equipment, do not plug a modem cable or telephone cable into an RJ-45 (network) jack.

Connecting to a local area network (LAN)


Use a LAN connection if you want to connect the computer directly to a router in your home (instead of working wirelessly), or if you want to connect to an existing network at your office.

Connecting to a LAN requires an 8-pin, RJ-45 (network) cable.

To connect the network cable, follow these steps:

1. Plug the network cable into the network jack **(1)** on the computer.
2. Plug the other end of the network cable into a network wall jack **(2)** or router.

📝 NOTE: If the network cable contains noise suppression circuitry **(3)**, which prevents interference from TV and radio reception, orient the circuitry end of the cable toward the computer.



4 Enjoying entertainment features

Use your HP computer as an entertainment hub to socialize via the webcam, enjoy and manage your music, and download and watch movies. Or, to make your computer an even more powerful entertainment center, connect external devices like speakers, headphones, or a gaming console.

Using the webcam

Your computer has an integrated webcam, a powerful social networking tool that allows you to communicate up close with friends and colleagues whether they are next door or on the other side of the world. With the webcam, you can stream video with your instant messaging software, capture and share video, and take photos.

- ▲ To start the webcam, from the Start screen, type **c**, and then select **Camera**.

For details about using the webcam, go to Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Using audio

On your HP computer, you can play music CDs, download and listen to music, stream audio content from the web (including radio), record audio, or mix audio and video to create multimedia. To enhance your listening enjoyment, attach external speakers or headphones.

Adjusting the volume

1. From the Start screen, point to the far-right upper or lower corner of the screen to display the charms.
2. Select **Settings**, and then click the speaker icon.
3. Adjust the slider to increase or decrease the volume.



NOTE: You can also adjust the volume using the volume keys on the external wireless keyboard. See [Using the action keys on page 32](#) for more information.

Connecting speakers

You can attach wired speakers to your computer by connecting them to a USB port on your computer.

To connect *wireless* speakers to your computer, follow the device manufacturer's instructions. Before connecting speakers, lower the volume setting.

Connecting headphones

You can connect wired headphones to the audio-out (headphone) jack/audio-in (microphone) jack on your computer.

To connect *wireless* headphones to your computer, follow the device manufacturer's instructions.

 **WARNING!** To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, see the *Regulatory, Safety and Environmental Notices*.

Using Beats Audio

You can experience Beats Audio through the computer's internal speakers or through Beats Audio headphones connected to the audio-out (headphone) jack/audio-in (microphone) jack.

Accessing Beats Audio

Use Beats Audio Control Panel to view and manually control audio and bass settings.

- ▲ To open Beats Audio Control Panel, from Start screen, type **c**, select **Control Panel**, select **Hardware and Sound**, and then select **Beats Audio Control Panel**.

Using video


Your HP computer is a powerful video device that enables you to watch streaming video from your favorite websites and download video and movies to watch on your computer without needing to connect to a network.

Connecting an HDMI device

 **NOTE:** To connect an HDMI device to your computer, you need an HDMI cable, sold separately.

You can connect high-definition devices to your computer, such as a gaming console or digital set-top box.

1. Connect one end of the HDMI cable to the HDMI-in port on the computer.



2. Connect the other end of the cable to the device.
3. If the computer screen does not automatically switch, press the HDMI-in button to alternate the computer screen to the HDMI device.
4. To make your selections, use the **enter**, back space, up arrow, or down arrow keys.

Using HDMI audio

HDMI is the only video interface that supports high-definition video *and* audio. HDMI controls are only intended to control the settings of the device plugged into that port, and do not control any other media devices on the system. When a device is plugged into the HDMI port, the volume on the computer is muted.

Managing your audio and video files

CyberLink MediaSuite helps you manage and edit your photo and video collections.

- ▲ To open CyberLink MediaSuite, from the Start screen, type **C**, and then select **CyberLink MediaSuite**.

For more information about using CyberLink MediaSuite, see the software Help.

Share media and data across your home group network (select models only)

Your computer has advanced features that allow you to connect your mobile devices and exchange photos, files, data, music, or videos. Using Near Field Communication (NFC) hardware and sMedio 360 software on your home group network, you can tap your NFC-enabled Android smart phone to your computer and wirelessly share information between your two devices.



IMPORTANT: sMedio works in both Windows 8 and Windows 7 operating systems. You can use sMedio on your computer as well as on other devices, as long as they are on the same home group network.

sMedio empowers you to:

- **Stream and share media** between mobile devices wirelessly with sMedio.
- **Migrate and synchronize data** between two computers on a wired or wireless home group network with sMedio TrueSync.
- **Tap your phone to your computer** to share photos, videos, and music to and from your phone and your computer with sMedio TrueLink+.



NOTE: To explore all of the available features of sMedio, go to the Windows desktop and click the **sMedio TrueSync** icon in the taskbar. Click **Learn More** on the Sign-in/Create Account screen.

Enable media sharing and set up a home group network

Before you can begin using sMedio software, you need to be sure that all of your computers and mobile devices are on the same home group network and media sharing is enabled.

1. Enable media sharing:
 - a. From the Start screen, point to the upper-right or lower-right corner of the display to reveal the charms.
 - b. Select **Settings**, and then click the network status icon.
 - c. Right-click the network you are connected to, and then select the check box to turn on sharing.
2. From the Start screen, click **sMedio**, and then click **Tutorial** for information on how to set up a home group network

Stream and share media between mobile devices

To wirelessly stream and share media from one device to another, your computers and mobile devices must be on the same home group network and media sharing must be enabled on all devices. See [Enable media sharing and set up a home group network on page 22](#) for more information.

- ▲ To wirelessly share media between devices, from the Start screen, select the sMedio 360.

– or –

From the Start screen, type **s**, and then select **sMedio 360** from the list of applications.

Migrate or synchronize data

With sMedio TrueSync, you can synchronize and access your files across multiple computers that are on the same home group network. You can also migrate files from one computer to another. For information on setting up a home group network, see [Enable media sharing and set up a home group network on page 22](#).

1. From the Windows desktop, click the **sMedio TrueSync** icon on the taskbar.
2. Follow the on-screen instructions to set up your folders that will be used for migrating and synchronizing information.

 **TIP:** You will also be guided through the process of setting up additional computers to create the synchronization relationship.

Share photos, videos, and music to and from your phone

sMedio TrueLink+ allows you to play back, stream, and share photos, videos, and music to and from your computer and NFC-enabled Android smart phone. Your computer and phone must be on the same home group network. For information on setting up a home group network, see [Enable media sharing and set up a home group network on page 22](#).

 **TIP:** For help in connecting the phone to your home group network, see the phone manufacturer's instructions.

Before you can begin sharing media, you must do the following:

1. Determine your Android phone operating system version.
2. Download the free app on your phone.
3. Share media between your devices.

Determining your Android phone operating system (OS) version

Your phone must have the Android 4.0 or higher operating system. Refer to the phone's manufacturer's instructions for NFC-enabled capabilities.

To determine the operating system version:

1. On your phone, go to the **Settings** screen, and then tap **About Phone**.
2. Tap **Android version**.

Download the sMedio TrueLink+ app to your phone

Download the sMedio TrueLink+ app to your phone to wirelessly touch-to-share photos, videos, and music from your NFC-enabled Android smart phone and your computer. This free app is located in the Google Play app store.

- ▲ Click the **Tutorial** icon on the sMedio main screen for instructions on downloading and using this app.

Start sharing media

Tap your phone to your computer to start sharing media.



NOTE: In order to share media from your phone to your computer, the media must be in a format that is compatible with other network devices.

1. On your phone, open the **sMedio 360 TrueLink+** app, tap **My Devices**, and then tap **My Mobile**.
2. Swipe left or right to find your music, videos, or photos.
3. Open the item you want to share.
4. Tap any part of your phone on the NFC label on the top of your computer.
5. A message, **Touch to Beam**, appears on the phone screen. Press and hold the item you are sharing for a few seconds.
6. In a few seconds, you are prompted on your computer to stream, copy, or cancel the file.

Depending on your choice, the file will begin moving to the correct folder on your computer.

5 Navigating using the keyboard and pointing devices

Your computer includes an external wireless keyboard and an external wireless mouse for easy navigation. After you remove the battery tabs from the accessories, they will automatically pair with the computer.



NOTE: The wireless receiver is preinstalled in the dedicated USB port on the bottom of the computer stand. If you have any problems with the wireless accessories, remove the receiver from the USB port and then reconnect it. For additional information, see [Keyboard and mouse problems on page 65](#).

Using touch screen gestures

A touch screen computer allows you to control items on the screen directly with your fingers.

 **TIP:** On touch screen computers, you can perform the gestures on the screen or using the keyboard and mouse.


One-finger slide

The one-finger slide is mostly used to pan or scroll through lists and pages, but you can use it for other interactions, too, such as moving an object.

- To scroll across the screen, lightly slide one finger across the screen in the direction you want to move.

 **NOTE:** When many apps are revealed on the Start screen, you can slide your finger to move the screen left or right.

- To drag, press and hold an object, and then drag the object to move it.



Tapping

To make an on-screen selection, use the tap function.


- Use one finger to tap an object on the screen to make a selection. Double-tap an item to open it.



Scrolling

Scrolling is useful for moving the pointer up, down, left, or right on a page or image.


- Place two fingers on the screen and then drag them in an up, down, left, or right motion.



Pinching/stretching

Pinching and stretching allows you to zoom out or in on images or text.

- Zoom in by placing two fingers together on the display and then move your fingers apart.
- Zoom out by placing two fingers apart on the display and then move your fingers together.




Rotating (select models only)

Rotating allows you to turn items such as photos.

- Anchor the forefinger of your left hand on the object you want to rotate. Using your right hand, slide your forefinger around in a sweeping motion from 12 o'clock to 3 o'clock. To reverse the rotation, move your forefinger from 3 o'clock to 12 o'clock.



NOTE: Rotate is intended for specific apps where you can manipulate an object or image. Rotate may not be functional for all apps.




Edge swipes

With edge swipes you can perform tasks such as changing settings and finding or using apps.

Right-edge swipe

The right-edge swipe reveals the charms, which let you search, share, start apps, access devices, or change settings.


- Gently swipe your finger inward from the right edge of the display onto the screen to reveal the charms.



Left-edge swipe

The left-edge swipe reveals your open apps so that you can switch to them quickly.


- Gently swipe your finger inward from the left edge of the display to switch between apps. Without lifting your finger, swipe back toward the left edge to reveal all open apps.



Top-edge swipe and bottom-edge swipe

The top-edge swipe or bottom-edge swipe allows you to open a list of apps available on your computer.

1. From the Windows Start screen, gently swipe your finger from the top edge or the bottom edge of the display onto the screen.
2. Tap **All apps** to view available apps.




Using the keyboard

With the keyboard, you can type to select items and perform the same functions as you do by using touch gestures. The keyboard also allows you to use action keys to perform specific functions.

 **TIP:** The Windows logo key  on the keyboard allows you to quickly return to the computer Start screen from an open app or the Windows desktop. Pressing the Windows logo key again will return you to the previous screen.

 **NOTE:** Depending on the country or region, your keyboard may have different keys and keyboard functions than those discussed in this section.



Component		Description
(1)	fn key	Executes frequently used system functions when pressed in combination with an action key.
(2)	 Windows logo key	Returns you to the Start screen from an open app or the Windows desktop. Pressing the key again returns you to the previous screen.
(3)	Action keys	Perform common tasks.
(4)	 Windows application key	Displays options for a selected object.
(5)	Volume keys	Mute or restore speaker sound, and decrease or increase speaker volume incrementally as long as you hold down the key.
(6)	Integrated numeric keypad	Set at the factory to function like an external numeric keypad. To alternate between this numeric function and the navigational function (indicated by the directional arrows on the keys), press the num lock key.
(7)	 Sleep key	Initiates Sleep, which saves your information in the system. The display and other system components turn off and power is conserved. To exit Sleep, briefly press the power button. CAUTION: To reduce the risk of information loss, save your work before initiating Sleep. WARNING! If a critical battery level occurs while the computer is in the Sleep state, the computer initiates Hibernation and the information stored is saved to the hard drive.

Using the action keys

An action key performs an assigned function. The icon on each of the **f1** through **f12** keys, and the volume (**5**), and Sleep (**7**) keys illustrates the assigned function for that key.

▲ To use an action key function, press and hold the key.

Icon	Key	Description
	f1	Allows you to view two apps simultaneously. The apps are displayed side by side.
	f2	Switches between open apps. NOTE: Continue to press this key until the app you want is displayed.
	f3	Shows the commands available in an app.
	f4	Shows a list of recently used apps.
	f5	Plays the previous track of an audio CD or the previous section of a DVD or a Blu-ray Disc (BD).
	f6	Begins, pauses, or resumes playback of an audio CD, a DVD, or a BD.
	f7	Stops playing an audio CD, DVD, or a BD.
	f8	Plays the next track of an audio CD or the next section of a DVD or a BD.
	f9	Opens the Search charm. Allows you to search an open app or another app, your computer, and the Internet.
	f10	Opens the Share charm. Allows you to share pictures, files, or webpages.
	f11	Opens the Devices charm. Allows you to set up printers and synchronize data with your phone and stream video to your wireless TV.
	f12	Opens the Settings charm. Allows you to personalize your computer: Change your account picture, specify the background and color of your Start screen, and more.
		Mutes or restores speaker sound.
		Decreases speaker volume incrementally as long as you hold down the key.

Icon	Key	Description
		Increases speaker volume incrementally as long as you hold down the key.
		Initiates Sleep, which saves your information in the system. The display and other system components turn off and power is conserved. To exit Sleep, briefly press the power button. CAUTION: To reduce the risk of information loss, save your work before initiating Sleep. WARNING! If a critical battery level occurs while the computer is in the Sleep state, the computer initiates Hibernation and the information stored is saved to the hard drive.

Using Microsoft Windows 8 shortcut keys

Microsoft Windows 8 provides shortcuts to perform actions quickly. Several shortcuts will help you with Windows 8 functions. Press the Windows logo key  in combination with a designated key in the table to perform the action.

For additional information on Windows 8 shortcut keys, go to **Help and Support**. From the Start screen, type **h**, and then select **Help and Support**.

Shortcut Keys

Shortcut key	Key	Description
		Returns you to the Start screen from an open app or the Windows desktop. Pressing the key again returns you to the previous screen.
	+ c	Opens the charms.
	+ d	Opens the Windows desktop.
	+ tab	Switches between open apps. NOTE: Continue to press this key combination until the app you want displays.
alt	+ f4	Closes an active app.

Using the integrated numeric keypad

The computer includes an external wireless keyboard that includes a numeric keypad.

Component	Description
num lock key	Controls the function of the integrated numeric keypad. Press the key to alternate between the standard numeric function found on an external keypad (this function is turned on at the factory) and the navigational function (indicated by the directional arrows on the keys). NOTE: The keypad function that is active when the computer is turned off is reinstated when the computer is turned back on.
Integrated numeric keypad	Set at the factory to function like an external numeric keypad. To alternate between this numeric function and the navigational function (indicated by the directional arrows on the keys), press the num lock key.

6 Managing power

Initiating Sleep and Hibernation

Windows has two power-saving states, Sleep and Hibernation.

- **Sleep**—The Sleep state is automatically initiated after a period of inactivity. Your work is saved to memory, allowing you to resume working very quickly. You can also initiate Sleep manually. For more information, see [Manually initiating and exiting Sleep on page 35](#).
- **Hibernation**—The Hibernation state is automatically initiated if the computer is in the Sleep state for an extended period. Hibernation puts your open documents and programs on your hard drive, and then turns off your computer.



NOTE: You can manually initiate Hibernation. See [Manually initiating and exiting Sleep on page 35](#) and [Manually initiating and exiting Hibernation on page 36](#).



CAUTION: To reduce the risk of possible audio and video degradation, loss of audio or video playback, or loss of information, do not initiate Sleep while reading from or writing to a disc or an external media card.



NOTE: You cannot connect to a network or perform any computer functions while the computer is in the Sleep state or in Hibernation.

Manually initiating and exiting Sleep

- ▲ To initiate Sleep, from the Start screen, point to the far-right upper or lower corner of the screen to display the charms. Click **Settings**, click the **Power** icon, and then select **Sleep**.

To exit Sleep:

- Briefly press the power button.
- Press a key on the keyboard.

When the computer exits Sleep, the power lights turn on and your work returns to the screen.



NOTE: If you have set a password to be required on wakeup, you must enter your Windows password before your work will return to the screen.

Manually initiating and exiting Hibernation

You can enable user-initiated Hibernation and change other power settings and timeouts using Power Options in Control Panel.

1. From the Start screen, type `power`, select **Settings**, and then select **Power Options**.
2. In the left pane, select **Choose what the power button does**.
3. Select **Change Settings that are currently unavailable**.
4. In the **When I press the power button** area, select **Hibernate**.
5. Click **Save changes**.

To exit Hibernation, briefly press the power button.

When the computer exits Hibernation, the power lights turn on and your work returns to the screen. If you have set a password to be required on wakeup, you must enter your Windows password before your work will return to the screen.

Setting password protection on wakeup

To set the computer to prompt for a password when the computer exits Sleep or Hibernation, follow these steps:

1. From the Start screen, type `power`, select **Settings**, and then select **Power Options**.
2. In the left pane, select **Require a password on wakeup**.
3. Select **Change Settings that are currently unavailable**.
4. Select **Require a password (recommended)**.

 **NOTE:** If you need to create a user account password or change your current user account password, click **Create or change your user account password**, and then follow the on-screen instructions. If you do not need to create or change a user account password, go to step 5.

5. Click **Save changes**.

Shutting down (turning off) the computer

 **CAUTION:** Unsaved information is lost when the computer shuts down.

The Shut down command closes all open programs, including the operating system, and then turns off the computer.

Shut down the computer under any of the following conditions:

- When you need to access components inside the computer
- When you are connecting an external hardware device to a port other than a USB or video port
- When the computer will be unused and disconnected from external power for an extended period

Although you can shut down the computer with the power button, the recommended procedure is to use the turn off command, as follows:



NOTE: If the computer is in the Sleep state or in Hibernation, you must first exit Sleep or Hibernation before shutdown is possible.

1. Save your work and close all open programs.
2. From the Start screen, point to the far-right upper or lower corner of the screen to display charms, and then click **Settings**.
3. Click the **Power** icon, and then click **Shut down**.

If the computer is unresponsive and you are unable to use the preceding shutdown procedures, try the following emergency procedures in the sequence provided:

- Press **ctrl+alt+delete**. Click the **Power** icon in the lower-right corner of the screen, and then click **Shut Down**.
- Press and hold the power button for at least 5 seconds.
- Press and hold the power button and the mute button.
- Disconnect the computer from external power.

7 Managing and sharing information

Drives are digital storage devices that help you store, manage, share, and access information. Your computer has an internal hard drive that stores your personal files and your computer's software and operating system. For added capacity or functionality, connect an external drive (purchased separately), such as an optical drive or hard drive.

To quickly transfer information, connect a USB flash drive to the USB port on your computer, or insert the memory card from your phone or camera into the memory card reader.



NOTE: For more information about required software and drivers, or to learn which computer port to use, see the manufacturer's instructions.

Using a USB device

Most computers have at least one USB port, because this versatile interface allows you to connect to numerous kinds of external devices to your computer.

Your computer may have more than one type of USB port. See [Getting to know your computer on page 5](#) for the types of USB ports on this computer. Be sure to purchase devices that are compatible with your computer.

Connecting a USB device

 **CAUTION:** To reduce the risk of damage to a USB connector, use minimal force to connect the device.

- ▲ Connect the USB cable for the device to the USB port.



A sound indicates that the device has been detected.

 **NOTE:** The first time you connect a USB device, a message displays on the Windows desktop and an icon in the notification area lets you know that the device is recognized by the computer.

Removing a USB device

 **CAUTION:** To reduce the risk of damage to a USB connector, do not pull on the cable to remove the USB device.

CAUTION: To reduce the risk of loss of information or an unresponsive system, use the following procedure to safely remove the USB device.


1. Save your information and close all programs associated with the device.
2. From the Windows desktop, click the hardware icon in the notification area, at the far right of the taskbar. A message, **Safely remove hardware and eject media** displays.
3. Follow the on-screen instructions.

Inserting and removing a memory card

To insert a memory card:

⚠ CAUTION: To reduce the risk of damage to the memory card connectors, use minimal force to insert a memory card.


1. Hold the card label-side up, with the connectors facing the computer.
2. Insert the card into the memory card reader, and then press in on the card until it is firmly seated.



A sound indicates that the device has been detected.

To remove a memory card:

1. Save your information and close all programs associated with the card.
2. From the Windows desktop, click the remove hardware icon in the notification area, at the far right of the taskbar. Then, follow the on-screen instructions.
3. Press in on the card **(1)**, and then remove it from the slot **(2)**.



8 Maintaining peak performance

Keep your computer at peak operating performance using the practices and tools described in this chapter. Start with routine maintenance, keep the equipment clean, and regularly update software. Also pay attention to important security issues, including passwords, virus protection, and anti-theft measures. Finally, find out how to access your system settings when you need to contact support or run diagnostics on your computer system.

Performing routine maintenance

Using Disk Cleanup

Disk Cleanup searches the hard drive for unnecessary files that you can safely delete to free up disk space and help the computer run more efficiently.

To run Disk Cleanup:

1. From the Start screen, type `disk`.
2. Click **Settings**, and then select **Free up disk space by deleting unnecessary files**.
3. Follow the on-screen instructions.

Using Disk Defragmenter

As you use your computer over time, the files on the hard drive become fragmented. Because of this, the hard drive works harder to locate files, and the computer slows down. Disk Defragmenter consolidates and reorganizes the fragmented files on the hard drive so that the system can run more efficiently.

Depending on the size of your hard drive and the number of fragmented files, Disk Defragmenter may need more than an hour to complete the task.

To run Disk Defragmenter:

1. From the Start screen, type `disk`.
2. Click **Settings**, and then select **Defragment and optimize your drives**.

Updating programs and drivers

HP recommends that you update your programs and drivers on a regular basis. Updates can resolve issues and bring new features and options to your computer.

Go to the HP support website to download the latest versions of HP programs and drivers. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html. At this location, you can also register to receive automatic notifications when updates become available.

Cleaning your computer

Use the following products to safely clean your computer:

- Dimethyl benzyl ammonium chloride 0.3 percent maximum concentration (For example: Disposable wipes, which come in a variety of brand names.)
- Alcohol-free glass cleaning fluid
- Water with mild soap solution
- Dry microfiber cleaning cloth or a chamois (static-free cloth without oil)
- Static-free cloth wipes

 **CAUTION:** Avoid strong cleaning solvents that can permanently damage your computer. If you are not sure that a cleaning product is safe for your computer, check the product contents to make sure that ingredients such as alcohol, acetone, ammonium chloride, methylene chloride, and hydrocarbons are not included in the product.

Fibrous materials, such as paper towels, can scratch the computer. Over time, dirt particles and cleaning agents can get trapped in the scratches.

Cleaning procedures

Follow the procedures in this section to safely clean your computer.

 **WARNING!** To prevent electric shock or damage to components, do not attempt to clean your computer while it is turned on.

Turn off the computer.

Disconnect external power.

Disconnect all powered external devices.

 **CAUTION:** To prevent damage to internal components, do not spray cleaning agents or liquids directly on any computer surface. Liquids dripped on the surface can permanently damage internal components.

Cleaning the display (All-in-Ones or Notebooks)

Gently wipe the display using a soft, lint-free cloth moistened with an *alcohol-free* glass cleaner. Be sure that the display is dry before closing the display.

Cleaning the sides or cover

To clean the sides or cover, use a soft microfiber cloth or chamois moistened with one of the cleaning solutions listed previously or use an acceptable disposable wipe.

 **NOTE:** When cleaning the cover of the computer, use a circular motion to aid in removing dirt and debris.

Cleaning the keyboard or mouse

-  **WARNING!** To reduce the risk of electric shock or damage to internal components, do not use a vacuum cleaner attachment to clean the keyboard. A vacuum cleaner can deposit household debris on the keyboard surface.
-  **CAUTION:** To prevent damage to internal components, do not allow liquids to drip between the keys.
-
- To clean the keyboard or mouse, use a soft microfiber cloth or a chamois moistened with one of the cleaning solutions listed previously or use an acceptable disposable wipe.
 - To prevent keys from sticking and to remove dust, lint, and particles from the keyboard, use a can of compressed air with a straw extension.

Using security measures

A password is a group of letters, numbers, and symbols that you choose to secure your computer information and to protect online transactions. Several types of passwords can be set. Some sites dictate the number and combination of letters, numbers, or symbols they require for passwords.

Use the following tips for creating and saving passwords:

- To reduce the risk of being locked out of the computer, record each password and store it in a secure place away from the computer. Do not store passwords in a file on the computer.
- Change your passwords frequently.
- Before you send your computer for service, back up your files, delete confidential files, and then remove all password settings.

For additional information about passwords, such as screen-saver passwords, go to Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Setting Windows passwords

Password	Function
User password	Protects access to a Windows user account.
Administrator password	Protects administrator-level access to computer contents.
	NOTE: This password cannot be used to access Computer Setup (BIOS) contents.

Setting Computer Setup (BIOS) passwords

Password	Function
Administrator password	• Must be entered each time you access Computer Setup (BIOS). • If you forget your administrator password, you cannot access Computer Setup (BIOS). NOTE: The administrator password can be used in place of the power-on password. NOTE: Your administrator password is not interchangeable with an administrator password set in Windows, nor is it revealed as it is set, entered, changed, or deleted. NOTE: If you enter the power-on password at the first password check, you must enter the administrator password to access Computer Setup (BIOS).
Power-on password	• Must be entered each time you turn on or restart the computer. • If you forget your power-on password, you cannot turn on or restart the computer. NOTE: The administrator password can be used in place of the power-on password. NOTE: A power-on password is not revealed as it is set, entered, changed, or deleted.

To set, change, or delete an administrator or power-on password in Computer Setup (BIOS):

1. To start Computer Setup (BIOS), turn on or restart the computer, quickly press **esc**, and then press **f10**.
2. Use the arrow keys to select **Security**, and then follow the on-screen instructions.

Your changes take effect when the computer restarts.

Using Internet security software

When you use your computer to access email, a network, or the Internet, you expose your computer to viruses, spyware, and other online threats. To help protect your computer, Internet security software that includes antivirus and firewall features is preinstalled on your computer.

- ▲ To access Norton Internet Security, from the Start screen, type **n**, and then select **Norton Internet Security**.

For more information about protecting your computer from Internet threats, go to Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Installing software updates

Installing Windows updates

Updates to the operating system and other software may have become available after the computer left the factory. Microsoft sends out alerts regarding critical updates. To protect the computer from security breaches and computer viruses, install all critical updates from Microsoft as soon as you receive an alert.

To be sure that all available updates are installed on the computer, observe these guidelines:

- Run Windows Update as soon as possible after you set up your computer. From the Start screen, type **u**, select **Settings**, and then select **Windows Update**.
- Enable automatic Windows Update thereafter.

Updating software

HP recommends that you regularly update the software and drivers that were originally installed on your computer. To download the latest versions, go to <http://www.hp.com/support>. At this location, you can also register to receive automatic update notifications when updates become available.

If you have installed software from other companies, regularly update the software to correct security problems and improve the performance of the software.

9 Using Computer Setup (BIOS) and HP PC Hardware Diagnostics (UEFI)

Computer Setup, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Computer Setup (BIOS) includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.

Starting Computer Setup (BIOS)

To start Computer Setup (BIOS), turn on or restart the computer, quickly press **esc**, and then press **f10**.



NOTE: Use extreme care when making changes in Computer Setup (BIOS). Errors can prevent the computer from operating properly.

Updating the BIOS

Updated versions of the BIOS may be available on the HP website.

Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*.

Some download packages contain a file named *Readme.txt*, which contains information regarding installing and troubleshooting the file.

Determining the BIOS version

To determine whether available BIOS updates contain later BIOS versions than those currently installed on the computer, you need to know the version of the system BIOS currently installed.

BIOS version information (also known as *ROM date* and *System BIOS*) can be revealed by pressing **fn+esc** (if you are already in Windows) or by using Computer Setup (BIOS).

1. Start Computer Setup (BIOS) (see [Starting Computer Setup \(BIOS\) on page 48](#)).
2. Use the arrow keys to select **File** and then select **System Information**.
3. To exit Computer Setup (BIOS) without saving your changes, use the arrow keys to select **File**, and then select **Ignore Changes and Exit**.
4. Select **Yes**.

Downloading a BIOS update

 **CAUTION:** To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC adapter. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

Do not disconnect power from the computer by unplugging the power cord from the AC outlet.

Do not shut down the computer or initiate Sleep.

Do not insert, remove, connect, or disconnect any device, cable, or cord.

1. From the Start screen, type `support`, and then select the **HP Support Assistant** app.
2. Click **Updates and tune-ups**, and then click **Check for HP updates now**.
3. Follow the on-screen instructions.
4. At the download area, follow these steps:
 - a. Identify the most recent BIOS update and compare it to the BIOS version currently installed on your computer. If the update is more recent than your BIOS, make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.

If the update is more recent than your BIOS, make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

 **NOTE:** If you connect your computer to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

BIOS installation procedures vary. Follow any instructions that are revealed on the screen after the download is complete. If no instructions are revealed, follow these steps:

1. From the Start screen, type `e`, and then select **File Explorer**.
2. Click your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder on your hard drive that contains the update.
4. Double-click the file that has an `.exe` extension (for example, *filename.exe*).

The BIOS installation begins.

5. Complete the installation by following the on-screen instructions.

 **NOTE:** After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

Using HP PC Hardware Diagnostics (UEFI)

HP PC Hardware Diagnostics is a Unified Extensible Firmware Interface (UEFI) that allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs outside the operating system so that it can isolate hardware failures from issues that are caused by the operating system or other software components.

To start HP PC Hardware Diagnostics UEFI:

1. Turn on or restart the computer, quickly press **esc**, and then press **f2**.

The BIOS searches three places for the HP PC Hardware Diagnostics (UEFI) tools in the following order:

- a. Connected USB drive



NOTE: To download the HP PC Hardware Diagnostics (UEFI) tool to a USB drive, see [Downloading HP PC Hardware Diagnostics \(UEFI\) to a USB device on page 50](#).

- b. Hard drive
- c. BIOS

2. Click the type of diagnostic test you want to run, and then follow the on-screen instructions.



NOTE: If you need to stop a diagnostic test, press **esc**.

Downloading HP PC Hardware Diagnostics (UEFI) to a USB device



NOTE: The HP PC Hardware Diagnostics (UEFI) download instructions are provided in English only.

1. Go to <http://www.hp.com>.
2. Click **Support & Drivers**, and then click the **Drivers & Software** tab.
3. Enter the product name in the text box, and then click **Search**.
4. Select your computer model, and then select your operating system.
5. In the **Diagnostic** section, click **HP UEFI Support Environment**.

– or –

Click **Download**, and then select **Run**.

10 Backing up, restoring, and recovering

Your computer includes tools provided by HP and Windows to help you safeguard your information and retrieve it if you ever need to. These tools will help you return your computer to a proper working state or even back to the original factory state, all with simple steps.

This chapter provides information about the following processes:

- Creating recovery media and backups
- Restoring and recovering your system



NOTE: This chapter describes an overview of backing up, restoring and recovering options. For more details about the tools provided, see Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Creating recovery media and backups

Recovery after a system failure is only as good as your most recent backup.

1. After you successfully set up the computer, create HP Recovery media. This step creates a backup of the HP Recovery partition on the computer. The backup can be used to reinstall the original operating system in cases where the hard drive is corrupted or has been replaced.

HP Recovery media you create will provide the following recovery options:

- System Recovery—Reinstalls the original operating system and the programs that were installed at the factory.
- Minimized Image Recovery—Reinstalls the operating system and all hardware-related drivers and software, but not other software applications.
- Factory Reset—Restores the computer to its original factory state by deleting all information from the hard drive and re-creating the partitions. Then it reinstalls the operating system and the software that was installed at the factory.

See [Creating HP Recovery media on page 52](#).

2. As you add hardware and software programs, create system restore points. A system restore point is a snapshot of certain hard drive contents saved by Windows System Restore at a specific time. A system restore point contains information that Windows uses, such as registry settings. Windows creates a system restore point for you automatically during a Windows update and during other system maintenance (such as a software update, security scanning, or system diagnostics). You can also manually create a system restore point at any time. For more information and steps for creating specific system restore points, see Help and Support. From the Start screen, type **h**, and then select **Help and Support**.
3. As you add photos, video, music, and other personal files, create a backup of your personal information. Windows File History can be set to regularly and automatically back up files from libraries, desktop, contacts, and favorites. If files are accidentally deleted from the hard drive and they can no longer be restored from the Recycle Bin, or if files become corrupted, you can restore the files that you backed up using File History. Restoring files is also useful if you ever choose to reset the computer by reinstalling Windows or choose to recover using HP Recovery Manager.



NOTE: File History is not enabled by default, so you must turn it on.

For more information and steps for enabling Windows File History, see Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Creating HP Recovery media

HP Recovery Manager is a software program that offers a way to create recovery media after you successfully set up the computer. HP Recovery media can be used to perform system recovery if the hard drive becomes corrupted. System recovery reinstalls the original operating system and the software programs installed at the factory, and then configures the settings for the programs. HP

Recovery media can also be used to customize the system or restore the factory image if you replace the hard drive.

- Only one set of HP Recovery media can be created. Handle these recovery tools carefully, and keep them in a safe place.
- HP Recovery Manager examines the computer and determines the required storage capacity for the blank USB flash drive or the number of blank DVD discs that will be required.
- To create recovery discs, your computer must have an optical drive with DVD writer capability, and you must use only high-quality blank DVD-R, DVD+R, DVD-R DL, or DVD+R DL discs. Do not use rewritable discs such as CD±RW, DVD±RW, double-layer DVD±RW, or BD-RE (rewritable Blu-ray) discs; they are not compatible with HP Recovery Manager software. Or instead you can use a high-quality blank USB flash drive.
- If your computer does not include an integrated optical drive with DVD writer capability, but you would like to create DVD recovery media, you can use an external optical drive (purchased separately) to create recovery discs, or you can obtain recovery discs for your computer from the HP website. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html. If you use an external optical drive, it must be connected directly to a USB port on the computer; the drive cannot be connected to a USB port on an external device, such as a USB hub.
- Be sure that the computer is connected to AC power before you begin creating the recovery media.
- The creation process can take up to an hour or more. Do not interrupt the creation process.
- If necessary, you can exit the program before you have finished creating all of the recovery DVDs. HP Recovery Manager will finish burning the current DVD. The next time you start HP Recovery Manager, you will be prompted to continue, and the remaining discs will be burned.

To create HP Recovery media:

1. From the Start screen, type `recovery`, and then select **HP Recovery Manager**.
2. Select **Recovery Media Creation**, and then follow the on-screen instructions.

If you ever need to recover the system, see [Recovering using HP Recovery Manager on page 56](#).

Restore and recovery

There are several options for recovering your system. Choose the method that best matches your situation and level of expertise:

- If you need to restore your personal files and data, you can use Windows File History to restore your information from the backups you created. For more information and steps for using File History, see Help and Support. From the Start screen, type **h**, and then select **Help and Support**.
- If you need to correct a problem with a preinstalled application or driver, use the Drivers and Applications Reinstall option of HP Recovery Manager to reinstall the individual application or driver.

From the Start screen, type **recovery**, select **HP Recovery Manager**, select **Drivers and Applications Reinstall**, and then follow the on-screen instructions.

- If you want to restore the system to a previous state without losing any personal information, Windows System Restore is an option. System Restore allows you to restore without the requirements of Windows Refresh or a reinstallation. Windows creates system restore points automatically during a Windows update and other system maintenance events. Even if you did not manually create a restore point, you can choose to restore to an automatically created restore point. For more information and steps for using Windows System Restore, see Help and Support. From the Start screen, type **h**, and then select **Help and Support**.
- If you want a quick and easy way to recover the system without losing your personal information, settings, or apps that came preinstalled on your computer or were purchased from the Windows Store, consider using Windows Refresh. This option does not require backing up data to another drive. See [Using Windows Refresh for quick and easy recovery on page 55](#).
- If you want to reset your computer to its original state, Windows provides an easy way to remove all personal data, apps, and settings, and reinstall Windows.

For more information, see [Remove everything and reinstall Windows on page 55](#).

- If you want to reset your computer using a minimized image, you can choose the HP Minimized Image Recovery option from the HP Recovery partition (select models only) or HP Recovery media. Minimized Image Recovery installs only drivers and hardware-enabling applications. Other applications included in the image continue to be available for installation through the Drivers and Applications Reinstall option in HP Recovery Manager.

For more information, see [Recovering using HP Recovery Manager on page 56](#).

- If you want to recover the computer's original factory partitioning and content, you can choose the System Recovery option from the HP Recovery partition (select models only) or use the HP Recovery media that you have created. For more information, see [Recovering using HP Recovery Manager on page 56](#). If you have not already created recovery media, see [Creating HP Recovery media on page 52](#).
- If you have replaced the hard drive, you can use the Factory Reset option of HP Recovery media to restore the factory image to the replacement drive. For more information, see [Recovering using HP Recovery Manager on page 56](#).
- If you wish to remove the recovery partition to reclaim hard drive space, HP Recovery Manager offers the Remove Recovery Partition option.

For more information, see [Removing the HP Recovery partition on page 58](#).

Using Windows Refresh for quick and easy recovery

When your computer is not working properly and you need to regain system stability, the Windows Refresh option allows you to start fresh and keep what is important to you.

 **IMPORTANT:** Refresh removes any traditional applications that were not originally installed on the system at the factory. Any Windows 8 apps that came preinstalled on your computer and any that were purchased from the Windows Store will be saved.

 **NOTE:** During Refresh, a list of removed traditional applications will be saved so that you have a quick way to see what you might need to reinstall. See Help and Support for instructions on reinstalling traditional applications. From the Start screen, type **h**, and then select **Help and Support**.

 **NOTE:** You may be prompted for your permission or password when using Refresh. See Help and Support for more information. From the Start screen, type **h**, and then select **Help and Support**.

To start Refresh:

1. From the Start screen, point to the upper-right or lower-right corner of the screen to reveal the charms.
2. Click **Settings**.
3. Click **Change PC settings** in the bottom-right corner of the screen, and then select **General** from the PC settings screen.
4. Scroll the right-side choices down to display **Refresh your PC without affecting your files**.
5. Under **Refresh your PC without affecting your files**, select **Get started**, and then follow the on-screen instructions.

Remove everything and reinstall Windows

Sometimes you want to perform detailed reformatting of your computer, or you want to remove personal information before you give away or recycle your computer. The process described in this section provides a speedy, simple way to return the computer to its original state. This option removes all personal data, apps, and settings from your computer, and reinstalls Windows.

 **IMPORTANT:** This option does not provide backups of your information. Before using this option, back up any personal information you wish to retain.

You can initiate this option by using the **f11** key or from the Start screen.

To use the **f11** key:

1. Press **f11** while the computer boots.
– or –
Press and hold **f11** as you press the power button.
2. Choose your keyboard layout.
3. Select **Troubleshoot** from the boot options menu.
4. Select **Reset your PC**, and then follow the on-screen instructions.

To use the Start screen:

1. From the Start screen, point to the upper-right or lower-right corner of the screen to reveal the charms.
2. Click **Settings**.
3. Click **Change PC settings** in the bottom-right corner of the screen, and then select **General** from the PC settings screen.
4. Scroll the right-side choices down to display **Remove everything and reinstall Windows**.
5. Under **Remove everything and reinstall Windows**, select **Get started**, and follow the on-screen instructions.

Recovering using HP Recovery Manager

HP Recovery Manager software allows you to recover the computer to its original factory state by using the HP Recovery media that you created or by using the HP Recovery partition (select models only). If you have not already created recovery media, see [Creating HP Recovery media on page 52](#).

Using HP Recovery media, you can choose from one of the following recovery options:

- System Recovery—Reinstalls the original operating system, and then configures the settings for the programs that were installed at the factory.
- Minimized Image Recovery (select models only)—Reinstalls the operating system and all hardware-related drivers and software, but not other software applications.
- Factory Reset—Restores the computer to its original factory state by deleting all information from the hard drive and re-creating the partitions. Then it reinstalls the operating system and the software that was installed at the factory.

The HP Recovery partition (select models only) allows System Recovery and Minimized Image Recovery.

What you need to know

- HP Recovery Manager recovers only software that was installed at the factory. For software not provided with this computer, you must either download the software from the manufacturer's website or reinstall the software from the media provided by the manufacturer.
- Recovery through HP Recovery Manager should be used as a final attempt to correct computer issues.
- HP Recovery media must be used if the computer hard drive fails. If you have not already created recovery media, see [Creating HP Recovery media on page 52](#).
- To use the Factory Reset option, you must use HP Recovery media. If you have not already created recovery media, see [Creating HP Recovery media on page 52](#).
- If the HP Recovery media does not work, you can obtain recovery media for your system from the HP website. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.



IMPORTANT: HP Recovery Manager does not automatically provide backups of your personal data. Before beginning recovery, back up any personal data you wish to retain.

Using the HP Recovery partition (select models only)

The HP Recovery partition (select models only) allows you to perform a system recovery or minimized image recovery without the need for recovery discs or a recovery USB flash drive. This type of recovery can only be used if the hard drive is still working.

To start HP Recovery Manager from the HP Recovery partition:

1. Press **f11** while the computer boots.
– or –
Press and hold **f11** as you press the power button.
2. Choose your keyboard layout.
3. Select **Troubleshoot** from the boot options menu.
4. Select **Recovery Manager**, and follow the on-screen instructions.

Using HP Recovery media to recover

You can use HP Recovery media to recover the original system. This method can be used if your system does not have an HP Recovery partition or if the hard drive is not working properly.

1. If possible, back up all personal files.
2. Insert the first HP Recovery disc you created into the optical drive on your computer or into an optional external optical drive, and then restart the computer.
– or –
Insert the HP Recovery USB flash drive you created into a USB port on your computer, and then restart the computer.



NOTE: If the computer does not automatically restart in HP Recovery Manager, change the computer boot order. See [Changing the computer boot order on page 57](#).

3. Follow the on-screen instructions.

Changing the computer boot order

If computer does not restart in HP Recovery Manager, you can change the computer boot order, which is the order of devices listed in BIOS where the computer looks for startup information. You can change the selection for an optical drive or a USB flash drive.

To change the boot order:

1. Insert the HP Recovery media you created.
2. Restart the computer, quickly press **esc**, and then press **f9** for boot options.
3. Select the optical drive or USB flash drive you want to boot from.
4. Follow the on-screen instructions.

Removing the HP Recovery partition

HP Recovery Manager software allows you to remove the HP Recovery partition to free up hard drive space.



IMPORTANT: After you remove the HP Recovery partition, you can no longer use the Windows Refresh option, the Windows option to remove everything and reinstall Windows, or the HP Recovery Manager option. So before you remove the Recovery partition, create HP Recovery media; see [Creating HP Recovery media on page 52](#).

Follow these steps to remove the HP Recovery partition:

1. From the Start screen, type `recovery`, and then select **HP Recovery Manager**.
2. Select **Remove Recovery Partition**, and then follow the on-screen instructions.

11 Troubleshooting

Wireless connection problems

Some possible causes for wireless connection problems include the following:

- Wireless device is not turned on.
- Wireless device is not installed correctly or has been disabled.
- Wireless device encountered interference from other devices.
- Wireless device or router hardware has failed.

Cannot connect to a WLAN

If you have a problem connecting to a WLAN, confirm that the integrated WLAN device is turned on and properly installed on your computer.

1. Be sure that the wireless device is turned on.
2. Then try connecting to the WLAN again.

If you are still unable to connect, follow the steps below.

1. From the Start screen, type **c**, and then select **Control Panel**.
2. Select **System and Security**, and then in the **System** area, click **Device Manager**.
3. Click the arrow next to **Network adapters** to expand the list and show all adapters.
4. Identify the WLAN device from the Network adapters list. The listing for a WLAN device may include the term *wireless*, *wireless LAN*, *WLAN*, or *802.11*.

If no WLAN device is listed, either your computer does not have an integrated WLAN device, or the driver for the WLAN device is not properly installed.

For more information about troubleshooting WLANs, see the website links provided in Help and Support.

Cannot connect to a preferred network

You may not be able to connect to a preferred network because it is a security-enabled WLAN. You must have the security code to connect to this type of WLAN. See the next section for additional information.

If entering a security code is not the problem, you may have a corrupted WLAN connection. Many times, Windows can automatically repair a corrupted WLAN connection.

- If there is a network status icon in the notification area, at the far right of the taskbar, right-click the icon, and then click **Troubleshoot problems**.

Windows resets your network device and attempts to reconnect to one of the preferred networks.

- If there is no network status icon in the notification area, follow these steps:
 1. From the Start screen, type **c**, and then select **Control Panel**.
 2. Select **Network and Internet**, and then select **Network and Sharing Center**.
 3. Select **Troubleshoot problems**, and then select the network you want to repair.

Current network security codes are unavailable

If you are prompted for a security code (or network key) or a name (SSID) when connecting to a WLAN, the network is protected by security. The SSID and security code are alphanumeric codes that you enter into your computer to identify your computer to the network. You must have the current codes to connect to a secure network.

- For a network connected to your personal wireless router, review the router user guide for instructions on setting up the same codes on both the router and the WLAN device.
- For a private network, such as a network in an office or at a public Internet chat room, contact the network administrator to obtain the codes, and then enter the codes when you are prompted to do so.

Some networks change the SSID or network keys used in their routers or access points on a regular basis to improve security. You must change the corresponding code in your computer accordingly.

If you are provided with a new wireless network key and SSID for a network, and if you have previously connected to that network, follow the steps below to reconnect to the network:

1. From the Windows desktop, click the network status icon in the notification area, at the far right of the taskbar.

A list showing the available WLANs is displayed. If you are in a hotspot where several WLANs are active, several will be displayed.

2. Right-click the network, and then click **Properties**.



NOTE: If the network you want is not listed, check with the network administrator to be sure that the router or access point is operating.

3. Click the **Security** tab and enter the correct wireless encryption data into the **Network security key** box.
4. Click **OK** to save these settings.

Cannot connect to the wireless router

If you are trying to connect to the wireless router and are unsuccessful, reset the wireless router by removing power from the router for 10 to 15 seconds.

If the computer still cannot connect to a WLAN, restart the wireless router. For details, see the router manufacturer's instructions.

Network status icon is not displayed

If the network status icon is not displayed in the notification area after you configure the WLAN, the software driver is either missing or corrupted. A Windows "Device not Found" error message may also be displayed.

To resolve this problem, get the latest version of the WLAN device software and drivers for your computer from <http://www.hp.com>.

1. Open your Internet browser.
2. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwwcontact_us.html.
3. Click the option for software and driver downloads, and then type your computer model number in the search box.
4. Press **enter**, and then follow the on-screen instructions.



NOTE: If the WLAN device you are using was purchased separately, consult the manufacturer's website for the latest software.

Power problems

Computer will not turn on or start

1. Shut down the computer.
2. Test the AC outlet by connecting a different electrical device to it.
3. Reconnect the computers cables, being sure that the connection from the AC adapter to the computer and the connection from the AC adapter to the AC outlet are secure.
4. Try to turn on the computer.
 - If the power lights turn on, the AC adapter is working properly.
 - If the connections are secure and the power lights remain off, the AC adapter is not functioning and should be replaced.

Contact support for information about obtaining a replacement AC power adapter.

Hard drive error

1. Press the **ctrl+alt+delete** keys simultaneously.
2. Click the **Power** icon, and then click **Restart**.

Or, press and hold the power button on the computer for 5 or more seconds to turn off the computer, and then press the power button to turn on the computer.
3. If Windows opens, immediately back up all important information to an external hard drive.
4. Whether Windows started or not, contact support. Either the hard drive or the system board may need to be replaced.

Computer is not responding

Use the Windows Task Manager to close any programs that are not responding.

1. Press the **ctrl+alt+delete** keys.
2. Click **Task Manager**.
3. Select any program that is not responding, and then click **End Task**.

If closing programs does not work, restart the computer.

1. Press the **ctrl+alt+delete** keys.
2. Click the **Power** icon, and then click **Restart**. Or, press and hold the power button on the computer for 5 or more seconds to turn off the computer, and then press the power button to turn on the computer.

Computer shuts down unexpectedly

- The computer might be in an exceedingly hot environment. Turn it off and let it cool down.
- Be sure that the computer vents are not blocked and that the internal fan is running. See [Getting to know your computer on page 5](#) for the location of the computer vents.

Computer Setup problems

The computer will not enter Computer Setup

If the computer will not enter Computer Setup when you press **f10**, press **fn+f lock**, and then try to start Computer Setup again.

Display problems

The display is blank

- Exit Sleep to redisplay the screen image.
 - Press the power button briefly.
 - Press a key on the keyboard.
 - Press the space bar.
 - Press the [esc](#) key.
- Press the power button to turn on the computer.

Images on the screen are too large or too small, or the images are fuzzy

Adjust the resolution settings.

1. From the Start screen, type [c](#), and then select **Control Panel**.
2. Select **Appearance and Personalization**.
3. Under **Display**, select **Adjust Screen Resolution**.
4. Adjust resolution as necessary, and then click **Apply**.

Keyboard and mouse problems

- Be sure that you are using the keyboard or mouse within range of the receiver.
- Be sure that the mouse is not in Suspend mode, which occurs after 20 minutes of inactivity. Click the left mouse button to reactivate it.
- Replace the batteries in the keyboard and mouse.
- Remove the wireless USB receiver on the bottom of the stand, and then reinsert it. Re-pair the keyboard and mouse to the receiver.



NOTE: The illustrations below may look slightly different from your keyboard and mouse.




IMPORTANT: During these steps, place the keyboard and mouse on the same level as the receiver.

To re-pair the keyboard and mouse:

1. Disconnect the receiver from the USB port on the bottom of the computer stand, and then reconnect it. See [Bottom on page 12](#) for the location of the USB port.




2. Be sure that the mouse is on **(1)**, and then press and hold the Connect button **(2)** for 5 to 10 seconds, until the LED on the receiver lights up or stops flashing. To confirm the connection, move the mouse and check for a response on the screen.



3. After the mouse connection is established, complete the following steps to re-pair the keyboard.

4. On the keyboard, press and hold the Connect button **(3)** for 5 to 10 seconds, until the LED on the receiver lights up or stops flashing.



Audio problems

No sound is produced

- Be sure that you connected powered speakers and that they are turned on.
- Adjust the volume, either on the speakers or through the computer operating system.
- Turn off your computer, and then unplug and reconnect the speakers. Be sure that the speakers are properly connected.
- Unplug headphones if they are connected to your computer (or speaker system).
- If the computer is in the Sleep state, exit Sleep by briefly pressing the power button.
- Check the audio functions.

To check the audio functions on your computer, follow these steps:

1. From the Start screen, type **c**, and then select **Control Panel**.
2. Select **Hardware and Sound**, and then select **Sound**.
3. When the Sound window opens, click the **Sounds** tab. Under **Program Events**, select any sound event, such as a beep or alarm, and click the **Test** button.

You should hear sound through the speakers or through connected headphones.

To check the recording functions on your computer, follow these steps:

1. From the Start screen, type **s**, and then select **Sound Recorder**.
2. Click **Start Recording** and speak into the microphone. Save the file to your Windows desktop.
3. Open a multimedia program and play back the sound.



NOTE: To confirm or change the audio settings on your computer, from the Start screen, type **c**, and then select **Control Panel**. Select **Hardware and Sound**, and then select **Sound**.

Software problems

- Shut down the computer, and then turn it on again.
- Update or reinstall the drivers. See [Updating programs and drivers on page 41](#).
- Refresh or restore your computer. See [Backing up, restoring, and recovering on page 51](#).

12 Specifications

Operating specifications

 **NOTE:** To see the electrical ratings, refer to your computer's ratings label, located on the outside of the computer, to determine the exact electrical rating.

Factor	Metric	U.S.
Operating temperature	5°C to 35°C	41°F to 95°F
Storage temperature	–30°C to 65°C	–22°F to 149°F
Operating humidity	15% to 80% @ 26°C	15% to 80% @ 78°F
Operating altitude	0 m to 2000 m	0 ft to 6561 ft
Storage altitude	0 m to 4572 m	0 ft to 15,000 ft

13 Electrostatic Discharge

Electrostatic discharge is the release of static electricity when two objects come into contact—for example, the shock you receive when you walk across the carpet and touch a metal door knob.

A discharge of static electricity from fingers or other electrostatic conductors may damage electronic components. To prevent damage to the computer, damage to a drive, or loss of information, observe these precautions:

- If removal or installation instructions direct you to unplug the computer, be sure that you are properly grounded before you unplug the computer or remove a cover.
- Keep components in their electrostatic-safe containers until you are ready to install them.
- Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.
- Use nonmagnetic tools.
- Before handling a component, discharge static electricity by touching an unpainted metal surface of the component.
- If you remove a component, place it in an electrostatic-safe container.

If you need more information about static electricity or assistance with component removal or installation, contact support.

Index

A

- AC adapter light, identifying 10
- action keys
 - identifying 31
 - next track or section 32
 - play, pause, resume 32
 - previous 32
 - stop 32
 - using 32
- antennas
 - Near Field Communication (NFC) 11
- audio for HDMI 21
- audio-in (microphone) jack, identifying 10
- audio-out (headphone) jack, identifying 10

B

- backing up
 - personal files 52
- backups 51
- Beats Audio 20
- Beats Audio Control Panel 20
- best practices 1
- BIOS
 - determining version 48
 - downloading an update 49
 - updating 48
- Bluetooth device 14
- Bluetooth label 13
- boot order
 - changing HP Recovery Manager 57
- bottom 13
- buttons
 - HDMI-in 12
 - power 11

C

- cables, USB 39
- caring for your computer 43
- cleaning your computer 43
- components
 - back 11
 - bottom 12
 - front 6
 - left-side 9
 - right-side 7
- computer reset 55
- Computer Setup (BIOS)
 - passwords 46
- Computer Setup (BIOS), using 48
- connecting to a WLAN 16
- corporate WLAN connection 16

D

- deleted files
 - restoring 54
- Disk Cleanup 41
- Disk Defragmenter software 41
- drivers, updating 41

E

- edge swipe gestures 29
- edge—swipe gestures
 - top-edge swipe 30
- electrical ratings 69
- electrostatic discharge 70

F

- fn key, identifying 31
- fun things to do 2

H

- hard drive light, identifying 8
- HDMI, using audio 21

- HDMI-in button, identifying 12
- HDMI-in port
 - connecting 20
- HDMI-in port, identifying 9
- headphone jack, identifying 10
- headphones, connecting 20
- Hibernation
 - exiting 36
 - initiating 36
- high-definition devices, connecting 20
- HP PC Hardware Diagnostics (UEFI)
 - downloading 50
- HP Recovery Manager
 - correcting boot problems 57
 - starting 57
- HP Recovery media
 - creating 52
 - recovery 57
- HP Recovery partition
 - recovery 57
 - removing 58
- hubs 38

I

- installing, critical updates 47
- integrated numeric keypad, identifying 31, 34
- integrated webcam light, identifying 6
- Internet connection setup 15
- Internet security software, using 46
- ISP 14

J

- jacks
 - audio-in (microphone) 10

audio-out (headphone) 10
RJ-45 (network) 8

K

keys
 fn 31
 Sleep 31
 volume 31
 Windows application 31
 Windows logo 31

L

labels
 Bluetooth 13
 regulatory 13
 serial number 13
 wireless certification 13
 WLAN 13
LAN, connecting 17
left-edge swipe 29
lights
 AC adapter 10
 hard drive 8
 webcam 6

M

maintenance, Disk
 Defragmenter 41
memory card reader, identifying 12
memory card, inserting 40
microphone jack, identifying 10
microphones, identifying 6
minimized image
 creating 56
minimized image recovery 57

N

Near Field Communication (NFC)
 antenna, identifying 11
NFC 22
NFC Android phone 23
num lock key, identifying 34

O

operating specifications 69
original system recovery 56

P

passwords
 Computer Setup (BIOS) 46
 Windows 45
pinching touch screen gesture 27
ports
 HDMI-in 9, 20
 USB 2.0 ports 8
 USB 3.0 7
 USB 3.0 (charging) powered 7
power button, identifying 11
power connector, identifying 10
product name and number, computer 13
programs, updating 41
public WLAN connection 16

R

re-pair, wireless keyboard and mouse 65
recovery
 discs 53, 57
 HP Recovery Manager 56
 media 57
 options 52
 refresh 55
 starting 57
 supported discs 53
 system 56
 USB flash drive 57
 using HP Recovery media 53
recovery media
 creating 52
 creating using HP Recovery Manager 53
recovery partition
 removing 58
recycle
 computer 54, 55
refresh
 computer 54
 recovery 54
 Windows 55
regulatory information
 regulatory label 13
 wireless certification labels 13
remove everything and reinstall Windows 55

reset
 computer 54, 55
 steps 55
restore
 Windows File History 54
right-edge swipe 29
RJ-45 (network) jack, identifying 8

S

security cable slot, identifying 10
security, wireless 15
serial number 13
serial number, computer 13
setting password protection on wakeup 36
setup of WLAN 15
sharing media 22
shortcut keys, Windows 8 33
shutdown 36
Sleep
 exiting 35
 initiating 35
Sleep key, identifying 31
slots
 security cable 10
sMedio 360 software 22
software
 CyberLink MediaSuite 21
 Disk Defragmenter 41
software updates, installing 47
software, updating 47
speakers
 connecting 19
speakers, identifying 6
specifications 69
subwoofer connector, identifying 8
supported discs
 recovery 53
system recovery 56
system restore point
 creating 52
 restoring 54

T

Touch screen gestures 29, 30
 edge-swipe gestures 29
 one-finger slide 26
 pinching 27

- rotating 28
- scrolling 27
- tapping 26
- Touch screen, using 26
- traveling with the computer 13
- troubleshooting 59
 - audio functions 67
 - computer is not responding 62
 - computer shuts down unexpectedly 62
 - computer will not turn on 62
 - display is blank 64
 - hard drive error 62
 - images on screen problems 64
 - keyboard 65
 - mouse 65
 - re-pair the wireless keyboard and mouse 65
 - software problems 68
 - wireless connection 59
- turning off the computer 36

U

- unresponsive system 36
- USB 2.0 ports, identifying 8
- USB 3.0 (charging) powered port, identifying 7
- USB 3.0 port, identifying 7
- USB cable, connecting 39
- USB devices
 - connecting 39
 - description 38
 - removing 39
- USB hubs 38

V

- video 20
- volume keys, identifying 31
- volume, adjusting 19

W

- webcam
 - using 19
- webcam light
 - identifying 6
- webcam light, identifying 6
- Windows
 - backup 52
 - File History 52, 54

- Refresh 54, 55
- reinstall 54, 55
- remove everything and reinstall option 55
- reset 55
- restoring files 54
- system restore point 52, 54
- Windows application key, identifying 31
- Windows logo key, identifying 31
- Windows passwords 45
- Windows updates, installing 47
- wired network, connecting 17
- wireless certification label 13
- wireless controls, operating system 14
- wireless light 14
- wireless network (WLAN)
 - connecting 16
 - corporate WLAN connection 16
 - equipment needed 15
 - functional range 16
 - public WLAN connection 16
 - security 15
 - using 15
- wireless router 15
- WLAN antennas, identifying 6
- WLAN device 13, 14
- WLAN label 13

Z

- zooming touch screen gesture 27