

ViewSonic®



VP3268-4K/VP3268-4K-CN Display User Guide

IMPORTANT: Please read this User Guide to obtain important information on installing and using your product in a safe manner, as well as registering your product for future service. Warranty information contained in this User Guide will describe your limited coverage from ViewSonic Corporation, which is also found on our web site at <http://www.viewsonic.com> in English, or in specific languages using the Regional selection box in the upper right corner of our website. “Antes de operar su equipo lea cuidadosamente las instrucciones en este manual”

Model No. VS16894

Thank you for choosing ViewSonic

As a world leading provider of visual solutions, ViewSonic is dedicated to exceeding the world's expectations for technological evolution, innovation, and simplicity. At ViewSonic, we believe that our products have the potential to make a positive impact in the world, and we are confident that the ViewSonic product you have chosen will serve you well.

Once again, thank you for choosing ViewSonic !



Contents

| | |
|--|-----------|
| 1. Cautions and Warnings | 1 |
| 2. Getting Started | 4 |
| 2-1. Package Contents | 5 |
| 2-2. The Exterior of the Monitor | 6 |
| 2-3. Hardware Installation | 7 |
| 2-4. Quick Installation | 14 |
| 2-5. Power On | 18 |
| 2-6. Driver Installation (Windows 10 Setup) | 19 |
| 3. Adjusting the Screen Image | 20 |
| 3-1. Using the Control Panel | 20 |
| 3-2. Monitor Optimization | 24 |
| 3-3. Setting the Timing Mode | 24 |
| 3-4. Additional Software Installation (Optional) | 26 |
| 3-5. Monitor Firmware Update (Optional) | 27 |
| 3-6. Auto Pivot (Optional) | 29 |
| 3-7. Colorbration (Optional) | 30 |
| 4. OSD Menu Introduction | 31 |
| 4-1. OSD Menu Tree | 31 |
| 4-2. OSD Menu Explanation | 41 |
| 4-3. Advanced Settings Explanation | 49 |
| 4-4. Advanced Settings for Gamers | 55 |
| 4-5. Monitor Setting Management | 56 |
| 5. Specifications | 58 |
| 6. Troubleshooting | 60 |

7. Cleaning and Maintenance 61
Safe Cleaning Practices 61

8. Compliance Information 63
8-1. FCC Compliance Statement 63
8-2. Industry Canada Statement 64
8-3. CE Conformity for European Countries..... 64
8-4. Declaration of RoHS2 Compliance 65
8-5. Indian Restriction of Hazardous Substances 67
8-6. Product Disposal at End of Product Life 67

9. Copyright Information..... 68

10. Service Information 69
Product Registration 69
Customer Service 70
Limited Warranty..... 73
Mexico Limited Warranty 78

1. Cautions and Warnings

1. Read these instructions completely before using the equipment.
2. Keep these instructions in a safe place.
3. Heed all warnings and follow all instructions.
4. Sit at least 18" / 45cm from the monitor.
5. When installing the monitor, please leave 10cm of open space around the monitor for ventilation safety purposes.
6. Always handle the display with care when moving it.
7. Exercise caution when removing the rear cover of the monitor. This monitor contains high-voltage parts.
8. Do not use this equipment near water. To reduce the risk of fire or electric shock, do not expose the monitor to rain or moisture.
9. Avoid exposing the monitor to direct sunlight or other sources of sustained heat. Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that may increase the temperature of the monitor to dangerous levels.
10. Clean with a soft, dry cloth. If further cleaning is required, see "Cleaning the Display" in this guide for further instructions.
11. Avoid touching the screen. Skin oils are difficult to remove.
12. Do not touch, rub or apply pressure to the monitor screen, as it may permanently damage the screen.
13. Place the monitor in a well-ventilated area. Do not place anything on the display that prevents heat dissipation.
14. Do not place heavy objects on the display, video cable, or power cord.

15. If smoke appears, an abnormal noise, or a strange odor is present, immediately switch the display off and call your dealer or ViewSonic. It is dangerous to continue using the display.
16. Do not attempt to circumvent the safety provisions of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade and the third prong are provided for your safety. If the plug does not fit into your outlet, obtain an adaptor and do not attempt to force the plug into the outlet.
17. When connecting to a power outlet, DO NOT remove the ground prong. Please ensure grounding prongs are NEVER REMOVED.
18. Protect the power cord from being treaded upon or pinched, particularly at the plug, and at the point where it emerges from the equipment. Be sure that the power outlet is located near the equipment so that it is easily accessible.
19. Only use attachments/accessories specified by the manufacturer.
20. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the equipment. When a cart is used, use with caution when moving the cart/equipment combination to avoid injury from tipping over.
21. Unplug this equipment when it will be unused for long periods of time.



22. Refer all servicing to qualified service personnel. Service will be required when the unit has been damaged in any way, such as: if the power-supply cord or plug is damaged, if liquid is spilled onto or objects fall into the unit, if the unit is exposed to rain or moisture, or if the unit does not operate normally or has been dropped.
23. Excessive sound pressure from ear-/headphones can cause hearing damage /hearing loss.
24. Adjustment of the volume control as well as the equalizer may increase the ear-/ headphones output voltage and therefore, the sound volume level.
25. The factors influencing the ear-/headphones output other than those specified by the manufacturer (e.g. operating system, equalizer software, firmware, driver) may increase the ear-/ headphone output voltage and therefore, the sound volume level.
26. **NOTICE: MONITOR MAY OVERHEAT AND SHUT DOWN!**
If monitor shut down, please reboot your monitor. After reboot, test the new Max Refresh rate by enabling it in the NVIDIA Control Panel.
If you don't see an image, please disconnect the DP cable and use the monitor OSD to try again with a safer Max Refresh.

2. Getting Started

Should problems arise and the product you have purchased needs to be returned for any reason, please keep the original packaging, registration form, and receipt. Having these items will make it easier for you to verify your product and repair, refund and/or return your product to you.

If you have any problems with your product or questions that have not been addressed in the User Guide, please contact customer service for help.

Important! Save the original box and all packing material for your future shipping needs.

NOTE: The word “Windows” in this user guide refers to Microsoft Windows operating system.

2-1. Package Contents

Your monitor package includes:

- Monitor
- Power cord
- Video cable¹
- USB cable
- Quick Start Guide
- ViewSonic CD
 - User Guide
 - INF/ICM files²
 - Registration information
 - Additional software (Optional)


NOTE:

¹ The video cables included in your package may vary depending on your country. Please contact your local reseller for more information.


² The INF file ensures compatibility with Windows operating systems, and the ICM file (Image Color Matching) ensures accurate on-screen colors. ViewSonic recommends that you install both the INF and ICM files.

2-2. The Exterior of the Monitor


A. Front



B. Left and Right



C. Rear



1. Control panel

(Expanded in 3-1)

2. I/O port (input/output)

This area should include all I/O connection options, as well as the power input connector (Expanded in 2-4)

3. Kensington security slot


(Expanded in 2-3 section G)

4. VESA wall mounting


This area on the back of the monitor*. For the VESA wall mounting installation steps, please see 2-3 section F for additional instructions.

2-3. Hardware Installation

A. Base Attachment Procedure




B. Base Removal Procedure



C. Adjusting the Monitor's Height


- Push the top of the monitor downward until it is at the desired viewing height for use.
- You can also pull the monitor back up, to the desired viewing height for use.



*This picture is for reference only

D. Adjusting the Angle

- After adjusting the monitor's height, stand in front of the monitor so it is centered in front of you.
- The angle of the screen can be adjusted by moving the panel, angling it forward or back. It can be adjusted from -5° to 21° for a flexible, comfortable viewing experience*.




*Adjustment angles vary depending on each individual model.


*This picture is for reference only

E. Pivot Feature

1. Lift/raise the monitor as high as it can go (max height).




2. Adjust the monitor, angling the top back and pull the bottom forward (see the below picture for reference).




*This picture is for reference only

3. Rotate the monitor clockwise and counterclockwise, (see the below picture for reference).



4. Finish the monitor installation by fully rotating the monitor 90°(see the below picture for reference).



*This picture is for reference only

F. Wall Mounting (Optional)

NOTE: For use only with a UL Listed Wall Mount Bracket.


To obtain a wall-mounting kit or height adjustment base, contact ViewSonic® or your local dealer. Refer to the instructions that come with the base mounting kit. To convert your display from a desk-mounted to a wall-mounted display, do the following:

1. Find VESA compatible wall-mounting kit which meets the quaternions in section "Specifications".
2. Verify that the power button is turned Off, then disconnect the power cord.
3. Lay the display face down on a towel or blanket.
4. Remove the base. (Screws removal might be required.)
5. Attach the mounting bracket from the wall mounting kit using screws of the appropriate length.
6. Attach the display to the wall, following the instructions in the wall-mounting kit.

G. Using the Kensington Lock

The Kensington security connector is located on the back side of the monitor. For more information on installation and usage please visit the Kensington website at <http://www.kensington.com>.

Below is an example of setting up the Kensington lock on a table for your reference.




*This picture is for reference only

2-4. Quick Installation

Connect Video Cable


1. Make sure both the LCD monitor and computer are turned OFF.
2. Remove rear panel covers if necessary.
3. Connect the video cable from the LCD monitor to the computer. Macintosh users: Models older than G3 require a Macintosh adapter. Attach the adapter to the computer and plug the video cable into the adapter.
To order a ViewSonic® Macintosh adapter, contact ViewSonic Customer Support.



3.A. Please do not connect the DisplayPort out on the monitor to the DisplayPort or mini DP connector on the computer. DisplayPort out is used for daisy chain connection (Explained in section D)

3.B. Video and Audio Cable


For a MAC with Thunderbolt output, please connect the “mini DP to DisplayPort cable” to the Thunderbolt output of MAC. And connect the other end of the cable to the DisplayPort connector on the rear of the monitor.



*This picture is for reference only

3.C. USB cable


Connect the B type connector of USB cable to the USB 3.0 upstream port on the rear of the monitor. And connect the A type connector of USB cable to the USB downstream port on the computer.



*This picture is for reference only

3.D. Power Cable (and AC/DC adapter if required)

Connect the female connector of AC power cord to the power connector of monitor, and the AC plug of AC power cord to the AC outlet.




*This picture is for reference only

2-5. Power On

Turn On LCD Monitor and Computer

Turn ON the LCD Monitor, then turn ON the computer. This particular order (LCD monitor before computer) is important.



NOTE: Windows users may receive a message asking them to install the INF file. To access the file, please insert ViewSonic CD into Computer's CD drive and locate within the following directory “:\CD\vsfiles”.

If your computer does not have a CD-ROM drive, please refer to Customer Support page.


Windows Users: Set the Timing Mode

For instructions on changing the resolution and refresh rate, see the graphics card's user guide.

2-6. Driver Installation (Windows 10 Setup)

In order to install the driver, first connect your monitor to your PC, boot up your PC (make sure to first turn on the monitor first) and make sure your internet is available. When the PC has finished booting up, your PC should auto- detect the monitor.

To ensure auto-detection is successful, go to ‘Advanced Display Settings’ under your system ‘Display Settings’ (screen resolution) window. There you can verify your ViewSonic monitor has been recognized by your PC in the ‘Color Management’ section of your advanced settings.




If your PC has not auto-detected the monitor, but is still functioning, you can download the driver from ViewSonic website and install it then restart your computer and follow the steps above again. It is not imperative for your computer to detect the monitor for normal use, but it is recommended.

If you encounter additional problems or have questions, please contact Customer Support.

3. Adjusting the Screen Image

3-1. Using the Control Panel

Use the buttons on the front or rear control panel to display and adjust OSD.....



Bezel & OSD symbol explanation

The bezel symbol explanation is stated below:

Standby Power On/Off



NOTE: Power light
Blue = ON
Orange = Power Saving



Display the Menu by pressing any Function button.

The OSD Menu and OSD Quick-Menu Symbol explanations and their functional uses are stated below.



Activation symbol to turn the various modes on when operating the menu system.



Activation symbol to exit, go back or deactivate the desired function that is selected.



Scrolls through menu options and adjusts the monitor controls.



Symbol used to go back or revert back to the previously selected menu



Information shortcut select button, which gives users access to the information of the monitor currently in use.



Main menu icon that allows users to access the main menu. Hold down the icon for a few seconds to turn off the main menu



Left and right icons toggle your selected choice horizontally.



OSD quick menu selector, which increases or decreases the currently selected function

The Quick-Menu symbol explanation is stated below:



1. To display the Quick Menu, press any one of the button on the slim bezel [0].
NOTE: All OSD menus and adjustment screens disappear automatically after about 15 seconds. This is adjustable through the OSD timeout setting in the setup menu.
2. After pressing one of the squares, you will see options appear for quick access.

| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| Preset Color Option | Contrast/ Brightness Option | Input Select Option | Main Menu Access | Exit |

3. After the desired menu control is selected, use the  symbols to navigate and adjust the monitor to your specified preference.
Each menu function is explained in further detail in 4-2 OSD Explanation.
4. To save the adjustments and exit, press [X] until the OSD disappears.

3-2. Monitor Optimization

- Adjust the computer's graphics card to support a recommended timing mode (refer to "Specifications" page for recommended resolution setting specific to your LCD monitor). To find instructions on "changing the refresh rate", please refer to the graphics card's user guide.

3-3. Setting the Timing Mode

Setting the timing mode is important for maximizing the quality of the screen image and minimizing eye strain. The timing mode consists of the resolution (example 3840 x 2160P) and refresh rate (or vertical frequency; example 60 Hz). After setting the timing mode, use the OSD (On-screen Display) controls to adjust the screen image.

For optimal picture quality, please use the recommended timing mode specific to your LCD monitor listed on the "Specification" page.

To set the Timing Mode:

- Please see your graphics card manager for adjusting the resolution and refresh rate.

Set up your widescreen LCD

Set your monitor resolution to its native resolution to get the best experience possible, with brilliant color and crisp text. Here is how:

1. Go to your display resolution settings window (each operating system will have a different process to get there).
2. Next, adjust the display resolution setting to match your monitor's native resolution. This will provide you with your best usage experience.

If you have difficulty setting the resolution or you do not see 3840 x 2160 as an available option, you may need a newer video card driver. Contact your computer or video card manufacturer to obtain the latest driver.

3-4. Additional Software Installation (Optional)


1. Load the ViewSonic CD on your CD/DVD drive.
2. Double click on the "Software" folder and choose an application, if desired.
3. Double click on the .exe file or .pkg file and follow the onscreen instructions to complete the simple installation for each additional software/application.
4. If your PC did not come with CD/DVD drive, please visit <http://color.viewsonic.com> for more VP series information. You can download VP exclusive applications from the website.

3-5. Monitor Firmware Update (Optional)

For the best display performance and to resolve any known issues, it is best to keep your monitor updated with the latest firmware version. With the USB cable and firmware update tool, you can easily update your monitor firmware any time.


Step1. Check and download the Firmware Update Tool with latest firmware version for your monitor from <http://color.viewsonic.com/support/software/>

Step2. Make sure your monitor USB upstream port has been connected to the PC USB downstream port. (Refer to 2-4. section C for more detail.)



Step3. Unzip the downloaded Firmware Update Tool, double click on the .exe file or .pkg file and follow the onscreen instructions to complete the simple installation.

Step4. Launch the Firmware Update Tool, the application will auto detect and verify your monitor model and current firmware version. Click Update to upgrade your monitor firmware.




Note: The update procedure will take a few minutes, please do not turn off the power of your PC and monitor. Disconnecting the USB connection will cause the update fail too.

3-6. Auto Pivot (Optional)

With the Auto Pivot application, the operating system can detect and adjust the image's orientation on the screen automatically when pivoting the screen vertically or horizontally. The application installation file is in the software folder of ViewSonic CD. Or you can check and download the latest version Auto Pivot application from <http://color.viewsonic.com/support/software/>

Note: Before applying the Auto Pivot function, please make sure monitor DDC/CI is set to On.



3-7. Colorbration (Optional)

To ensure long-term color accuracy, some specific models support hardware color calibration function. The monitor comes with Colorbration application. The application installation file is in the software folder of ViewSonic CD. Or you can download the latest version from <http://color.viewsonic.com/support/software/>

Standard monitor packing does not contain the color sensor which Colorbration application need to work with.


ViewSonic's Colorbration kit includes the CS-XRi1 color sensor, which has been co-developed with X-Rite to provide the best solution for displaying long-term color accuracy. CS-XRi1 is X-Rite's next generation colorimeter, which utilizes a redesigned optical system, filter technology, calibration architecture, and intelligent form factor to be paired with Viewsonic's Colorbration application to deliver unrivaled color accuracy, repeatability, and device longevity.

Note: Best with ViewSonic CS-XRi1, compatible with X-Rite i1Display Pro and i1 Pro 2.


4. OSD Menu Introduction

4-1. OSD Menu Tree

For an explanation of the OSD tree and pertaining functions, please refer to the 4-2 OSD explanation below. The OSD tree visually represents the complete OSD menu that can be accessed by your monitor. If you aren't sure where an option/function is or cannot locate a specific feature, please utilize the OSD tree below.



| Startup Menu | |
|---------------------|-----------------------------|
| Preset Color | sRGB |
| | EBU |
| | SMPTE-C |
| | REC709 |
| | DICOM SIM |
| | CAL 1 |
| | CAL 2 |
| | CAL3 |
| | CUSTOM |
| Contrast/Brightness | Contrast (-/+) |
| | Brightness (-/+) |
| Input Select | mini DP |
| | DISPLAYPORT |
| | HDMI 1 |
| | HDMI 2 |
| Menu | Menu OSD table detail items |
| Exit (OSD off) | |



| Menu | | | | | |
|--------------|-------------|-------------|--|--|--|
| Input Select | mini DP | | | | |
| | DISPLAYPORT | | | | |
| | HDMI 1 | | | | |
| | HDMI 2 | | | | |
| | Auto detect | On | | | |
| Audio Adjust | | Off | | | |
| | Volume | (-/+) | | | |
| | Mute | On | | | |
| | | Off | | | |
| | Audio Input | Auto | | | |
| | | mini DP | | | |
| | | DisplayPort | | | |
| | | HDMI 1 | | | |
| | | HDMI 2 | | | |
| | Sonic Mode | Audio In | | | |
| | | Standard | | | |
| | | Music | | | |
| Audio Only | Theater | | | | |
| | On | | | | |
| | Off | | | | |

Menu

| | | | | | | |
|-----------------|-----------|--------------|---------------------|--------------------|-------|--|
| ViewMode | Off | | | | | |
| | Game | FPS 1 | | | | |
| | | FPS 2 | | | | |
| | | RTS | | | | |
| | | MOBA | | | | |
| | Movie | | | | | |
| | Web | | | | | |
| | Text | | | | | |
| | MAC | UltraClear | (-/+) | | | |
| | Designer | CAD/CAM | Ultra Clear | (-/+) | | |
| | | | Advanced Sharpness | (-/+) | | |
| | | | Advanced Gamma | (-/+) | | |
| | | Animation | Ultra Clear | (-/+) | | |
| | | | Advanced Sharpness | (-/+) | | |
| | | | Black stabilization | (-/+) | | |
| | | Video Edit | Ultra Clear | (-/+) | | |
| | | | Advanced Sharpness | (-/+) | | |
| | | | Advanced Gamma | (-/+) | | |
| | | Photographer | Retro | Ultra Clear | (-/+) | |
| | | | | Advanced Sharpness | (-/+) | |
| | | | | Advanced Gamma | (-/+) | |
| | Photo | | Ultra Clear | (-/+) | | |
| | | | Advanced Sharpness | (-/+) | | |
| | | | Advanced Gamma | (-/+) | | |
| | | | TruTone | (-/+) | | |
| | Landscape | | Ultra Clear | (-/+) | | |
| | | | Advanced Sharpness | (-/+) | | |
| | | | Advanced Gamma | (-/+) | | |
| | | | | TruTone | (-/+) | |

Menu

| | | | | |
|---------------------|-------------------------|---------------------|---------------------|-------|
| ViewMode | Photographer | Portrait | Ultra Clear | (-/+) |
| | | | Advanced Sharpness | (-/+) |
| | | | Advanced Gamma | (-/+) |
| | | | TruTone | (-/+) |
| | | | Skin Tone | (-/+) |
| | | | Black stabilization | (-/+) |
| | | Mono Chrome | Advanced Sharpness | (-/+) |
| | | | TruTone | (-/+) |
| Color Adjust | Contrast/ Brightness | Contrast | (-/+) | |
| | | Brightness | (-/+) | |
| | Color Format | Auto | | |
| | | RGB (Full Range) | | |
| | | RGB (Limited Range) | | |
| | | YUV (Full Range) | | |
| | | YUV (Limited Range) | | |
| | | | | |
| | Standard Color | sRGB | | |
| | | EBU | | |
| | | SMPTE-C | | |
| | | REC 709 | | |
| | | DICOM SIM | | |
| | | | | |
| | Custom | Color Temperature | Panel Default | |
| | | | Bluish | |
| | | | Cool | |
| | | | Native | |
| | | | Warm | |
| | | | User | |
| | | Gamma | Off | |
| | | | 1.8 | |
| 2.0 | | | | |
| 2.2 | | | | |
| 2.4 | | | | |
| 2.6 | | | | |
| Black Stabilization | (-/+) | | | |
| Advanced DCR | (-/+) | | | |

Menu

| | | | | |
|----------------------------|--------------------------|-----------------|---------------|-------|
| Color Adjust | Custom | Gain | Red | (-/+) |
| | | | Green | (-/+) |
| | | | Blue | (-/+) |
| | | Offset | Red | (-/+) |
| | | | Green | (-/+) |
| | | | Blue | (-/+) |
| | | Hue | Red | (-/+) |
| | | | Green | (-/+) |
| | | | Blue | (-/+) |
| | | | Cyan | (-/+) |
| | | | Magenta | (-/+) |
| | | | Yellow | (-/+) |
| | | Saturation | Red | (-/+) |
| | | | Green | (-/+) |
| | | | Blue | (-/+) |
| | | | Cyan | (-/+) |
| | | | Magenta | (-/+) |
| | | | Yellow | (-/+) |
| | Recall | | | |
| | Color Calibration | CAL 1 | CAL Time Flag | |
| | | CAL 2 | CAL Time Flag | |
| CAL 3 | | CAL Time Flag | | |
| Calibration Notice | | Remind Schedule | | |
| | | Hour +/- | | |
| Counter Hour | | | | |
| Recall | | | | |
| Manual Image Adjust | Sharpness | (-/+) | | |
| | Aspect Ratio | 1:1 | | |
| | | 4:3 | | |
| | | Full Screen | | |
| | Overscan | On | | |
| | | Off | | |
| | Low Input lag | Off | | |
| | | Advanced | | |
| UltraFast | | | | |

Menu

| | | | | |
|---------------------|-------------------|---------------------|--|--|
| Manual Image Adjust | Response Time | Standard | | |
| | | Advanced | | |
| | | Ultra Fast | | |
| | Blue Light Filter | (-/+) | | |
| | Uniformity | On | | |
| | | Off | | |
| | HDR10 | On | | |
| | | Off | | |
| | Film Mode | On | | |
| | | Off | | |
| Setup Menu | Language | English | | |
| | | Français | | |
| | | Deutsch | | |
| | | Español | | |
| | | Italiano | | |
| | | Suomi | | |
| | | Русский | | |
| | | Türkçe | | |
| | | 日本語 | | |
| | | 한국어 | | |
| | | 繁體中文 | | |
| | | 简体中文 | | |
| | Resolution Notice | On | | |
| | | Off | | |
| | Information | Information message | | |
| | OSD Timeout | (-/+) | | |
| | OSD Background | On | | |
| | | Off | | |
| | OSD Pivot | Auto | | |
| | | 0° | | |
| | | +90° | | |
| | | -90° | | |
| Power Indicator | 180° | | | |
| | On | | | |
| | Off | | | |

Menu

| | | | | | |
|-------------------|----------------|---------------------------|-------------------------|-------------|--------|
| Setup Menu | Auto Power Off | On | | | |
| | | Off | | | |
| | Sleep | 30 Minutes | | | |
| | | 45 Minutes | | | |
| | | 60 Minutes | | | |
| | | 120 Minutes | | | |
| | | Off | | | |
| | | Off | | | |
| | Multi-Picture | Quad Windows | Top-Left Source Select | mini DP | |
| | | | | DisplayPort | |
| | | | | HDMI 1 | |
| | | | HDMI 2 | | |
| | | | Top-Right Source Select | mini DP | |
| | | | | DisplayPort | |
| | | HDMI 1 | | | |
| | | Bottom-Left Source Select | miniDP | | |
| | | | DisplayPort | | |
| | | | HDMI 1 | | |
| | | | | | HDMI 2 |

Menu

| | | | | |
|-------------------|--|----------------|----------------------|-------------|
| Setup Menu | Multi-Picture | PBP Top-Bottom | Top Source Select | miniDP |
| | | | | DisplayPort |
| | | | | HDMI 1 |
| | | | | HDMI 2 |
| | | | Bottom Source Select | miniDP |
| | | | | DisplayPort |
| | | HDMI 1 | | |
| | | HDMI 2 | | |
| | | Swap | | |
| | | PBP Left-Right | Left Source Select | miniDP |
| | | | | DisplayPort |
| | | | | HDMI 1 |
| | | | | HDMI 2 |
| | | | Right Source Select | miniDP |
| | | | | DisplayPort |
| | | HDMI 1 | | |
| | | HDMI 2 | | |
| | | Swap | | |
| | | PIP | PIP Source Select | mini DP |
| | | | | DisplayPort |
| HDMI 1 | | | | |
| HDMI 2 | | | | |
| PIP Position | PIP H. Position (-/+) PIP V. Position (-/+) | | | |
| PIP Size | (-/+) | | | |
| Swap | | | | |

Menu

| | | | | |
|-------------------|-----------------|------------|-----------|--|
| Setup Menu | Multi-Picture | Dual Color | sRGB | |
| | | | EBU | |
| | | | SMPTE-C | |
| | | | REC 709 | |
| | | | DICOM SIM | |
| | | | Native | |
| | | | CAL 1 | |
| | | | CAL 2 | |
| | | | CAL 3 | |
| | | | View Mode | |
| | | | : | |
| | | | View Mode | |
| | ECO Mode | Standard | | |
| | | | Optimize | |
| | | | Conserve | |
| | DisplayPort 1.2 | On | | |
| | | Off | | |
| | HDMI2.0 | On | | |
| | | Off | | |
| | DDC/CI | On | | |
| | | Off | | |
| | Save As | User 1 | | |
| | | User 2 | | |
| | | User 3 | | |
| | | Recall | | |
| | All Recall | | | |

4-2. OSD Menu Explanation

NOTE: The OSD menu items listed in this section indicate the entire OSD items of all models. Some of these items may not exist in your product OSD. Please disregard OSD menu item explanations if they do not exist in your OSD Menu. Please refer to the 4-1 OSD Tree (above), for your monitor's available OSD menu items. Please refer to the OSD explanation below (in alphabetical order), for a clearer explanation of what each function does.

A Advanced DCR

Advanced DCR technology automatically detects the image signal and intelligently controls the backlight brightness and color, to improve on the ability to make the black blacker in a dark scene, and make the white whiter in a bright environment.

Audio adjust

Adjusts the volume, mutes the sound, or toggles between inputs if you have more than one source.

Auto detect

If current input source is no signal, monitor will automatically switch to next input option. This function on some model is disabled by default.

B Backlight sensor

1. Maintains AdobeRGB, sRGB, and DICOM brightness stability for extended periods of time.
2. Typically, monitors take 30 minutes or more for brightness, chromaticity, and tone characteristics to stabilize; VP2785-4K can achieve stabilization in a mere three minutes.
3. For standard color and native modes, the backlight sensor will automatically adjust and maintain brightness to meet user defined brightness criteria, such as 120Cd/m², 160Cd/m², or 230Cd/m².

B Black stabilization

ViewSonic's Black stabilization provides heightened visibility and detail by brightening dark scenes.

Blue light filter

Adjusts the filter that blocks high-energy blue light for a safer experience for our users.

Brightness

Adjusts background black levels of the screen image.

C Color space

Allows users to choose which color space they would like to use for monitor color output (RGB, YUV).

Color temperature

Allows users to select specific color temperature settings to further customize their viewing experience.

| Panel Default | Panel original status |
|---------------|---|
| Bluish | 9300K |
| Cool | 7500K |
| Native | Native is a default color temperature. Recommend for general graphic design and regular use. |
| Warm | 5000K |

Contrast

Adjusts the difference between the image background (black level) and the foreground (white level).

C Color calibration

User can calibrate the monitor by ViewSonic Colorbration application with specific color sensor.

| Options | Sub | Explanation |
|--------------------|-------------------|---|
| CAL1 | | Display with the 1 st user calibration mode |
| CAL2 | | Display with the 2 nd user calibration mode |
| CAL3 | | Display with the 3 rd user calibration mode |
| Calibration Notice | Reminder Schedule | Set the schedule of calibration remind message |
| | Counter | To show the time accumulate from last calibration |
| Recall | | Reset the Color Calibration related settings to default |

Color format

Monitor can detect the input signal color format automatically. You can manually change the color format options to fit the correct color format range if the colors are not displayed correctly.

| Options | Explanation |
|---------------------|---|
| Auto | Monitor automatically recognizes the color format and black white levels. |
| RGB (Full Range) | The input signal color format is RGB and the black white level is full |
| RGB (Limited Range) | The input signal color format is RGB and the black white level is limited |
| YUV (Full Range) | The input signal color format is YUV and the black white level is full |
| YUV (Limited Range) | The input signal color format is YUV and the black white level is limited |

F Film mode

Enhanced picture quality is used to smooth out frame transitions while watching video. Film mode is only available for videos with a frame rate of 24fps.

G Gain

Adjust white temperature to customize your USER COLOR (can be saved in User Mode) or a specific color temperature and gain value (red, green, blue) use this setting.

Game mode

Integrating a gaming-oriented OSD design including pre-calibrated FPS, RTS and MOBA gaming settings, each mode is functionally customized with in-game testing and adjustments made for the best blend of color and technology.

Gamma

Allows users to manually adjust the brightness level of the monitor's grayscale levels. There are five selections: 1.8, 2.0, 2.2, 2.4, and 2.6.

H HDR10 (High-Dynamic-Range)

Reduces the overall contrast of a given scene so that detail in the highlights and shadows can be seen.*

*Only available on HDR 10 video content.

Hue

Adjusts the hue of each color (red, green, blue, cyan, magenta and yellow).

I Information

Displays the timing mode (video signal input) coming from the graphics card in the computer, the LCD model number, the serial number, and the ViewSonic® website URL. See your graphics card's user guide for instructions on changing the resolution and refresh rate (vertical frequency).

NOTE: VESA 1024 x 768 @ 60Hz (example) means that the resolution is 1024 x 768 and the refresh rate is 60 Hertz.

I Input select

Toggles between the various input options that are available for that particular monitor.

L Low input lag

ViewSonic offers low input lag, utilizing a monitor process reducer, which decreases signal latency. Under the low input lag submenu, you can select the appropriate speed for your desired use from the two options

M Manual image adjust

Displays the Manual Image Adjust menu. You can manually set a variety of image quality adjustments.

Memory recall

Returns the adjustments back to factory settings if the display is operating in a factory Preset Timing Mode listed in the Specifications of this manual.

* **Exception:** This control does not affect changes made with the Language Select or Power Lock setting

Multi-picture

Under MULTI-PICTURE MODE you can select the following settings, QUAD WINDOW, PBP TOP-BOTTOM, PBP LEFT-RIGHT, and PIP. The explanations for each setting are below.

1. QUAD WINDOWS: You can select four picture split screen type.
2. PBP TOP-BOTTOM: You can select two picture split screen types, and display two pictures side-by-sides on the top and bottom.
3. PBP LEFT-RIGHT: You can select 2 picture split screen types, and display 2 pictures side-by-side on the left and right.
4. PIP: Two picture split screen types, display large and the small pictures on the screen.
5. PIP SIZE: This controls the size of the sub-picture used in PIP.
6. PIP POSITION: This controls the position of sub-picture used in PIP mode.
7. PIP SWAP: This swaps the main-picture source and the sub-picture source.
8. SOURCE SELECT: This selects the source of the MULTI-PICTURE use in the QUAD WINDOW, PBP TOP-BOTTOM, PBP LEFT-RIGHT and PIP.

O Offset

Adjusts black levels for red, green and blue.

The gain and offset functions allow users to control the white balance for the upmost control when manipulating contrast and dark scenes.

OSD pivot

Set monitor OSD screen display direction.

| Options | Explanation |
|---------|--|
| Auto | With built-in G sensor, the OSD can auto pivot when positioned vertically. |
| 0° | Set the OSD screen without pivot |
| +90° | Set the OSD screen +90° pivot |
| -90° | Set the OSD screen -90° pivot |
| 180° | Set the OSD screen 180° pivot |

Overscan

Refers to a cropped image on your monitor screen. A setting on your monitor zooms in on movie content, so that you can't see the outermost edges of the film.

P Preset color mode

Monitor comes with several display industry color standards. Each color mode can be selected for specific monitor application.

| Options | Explanation |
|-----------|---|
| AdobeRGB | Precise color gamut and gamma of AdobeRGB (1998) standard |
| sRGB | Precise color gamut and gamma of sRGB standard |
| EBU | Precise color gamut and gamma of European Broadcasting Union standard |
| SMPTE-C | Precise color gamut and gamma of SMPTE-C standard |
| REC709 | Precise color gamut and gamma of ITU-R Rec. 709 standard |
| DICOM SIM | Gamma curve are set to a DICOM simulation |
| Native | Original color presented by the LCD panel |

R

Recall

Resets the Veivmode monitor settings.

Resolution notice

The notice tells users that the current viewing resolution is not the correct native resolution. This notice will appear in the display settings window, when setting up the display resolution.

Response time

Adjusts the response time, creating smooth images without streaking, blurring or ghosting. A low response time is perfect for the most graphic-intensive gaming, and provides amazing visual quality while watching sports or action movies.

S

Saturation

Adjusts the color depth of each color (red, green, blue, cyan, magenta and yellow)

Save as

The OSD save function is located in the main menu. There are 3 main positions (USER MODE 1, USER MODE 2, USER MODE3), which allows users to save their OSD settings.

Setup menu

Adjusts On-screen Display (OSD) settings. Many of these settings can activate on-screen display notifications so users do not have to reopen the menu.

Sharpness

Adjusts the sharpness and picture quality of the monitor.

S Standard color

Monitor comes with several display industry color standards. Each color mode can be selected for specific monitor application.

| Options | Explanation |
|-----------|---|
| Adobe RGB | Precise color gamut and gamma of Adobe RGB standard. |
| sRGB | Precise color gamut and gamma of sRGB standard |
| EBU | Precise color gamut and gamma of European Broadcasting Union standard |
| SMPTE-C | Precise color gamut and gamma of SMPTE-C standard |
| DCI-P3 | Precise color gamut and gamma of DCI-P3 standard. |
| REC709 | Precise color gamut and gamma of ITU-R Rec. 709 standard |
| DICOM SIM | Gamma curve are set to a DICOM simulation |
| Native | Original color presented by the LCD panel |
| iPhone | Precise color gamut and gamma |

U Uniformity

The Uniformity Correction function compensates any luminance and color uniformity imbalance on the screen, such as dark spots, uneven brightness, or illegible images on the screen. With the ViewSonic uniformity correction function, gray-scale levels become more balanced, and delta E scores are improved which increases reliability and provides the highest quality viewing experience from every monitor.

NOTE: If the uniformity function is enabled, it will reduce the overall peak luminance of the display.

V ViewMode

ViewSonic's unique ViewMode feature offers "Game," "Movie," "Web," "Text," and "Mono" presets. These presets are specifically designed to deliver an optimized viewing experience for different screen applications.

4-3. Advanced Settings Explanation

These settings have been explained in the OSD menu section above. Their functional use and instructions on setup are below.

1. Mult-Picture

Activate your OSD menu

Step 1: press the '1' on your ViewSonic Monitor bezel, to open the OSD (on screen display)

Step 2: Use the arrows to select the 'Manual Image Adjust' feature

Step 3: Use the arrow (buttons) to select the 'Multi-Picture' feature

Step 4: Next choose from the 'Multi-Picture' options-

| |
|----------------|
| Quad Windows |
| PBP Top-Bottom |
| PBP Left-Right |
| PIP |

Step 5: After choosing your 'Multi-Picture' option, repeat steps 1 through 3 to go back to the 'Multi-Picture' options screen.

Step 6: Select the 'Source Select' option

Step 7: Choose the source you would like to display based on the chosen 'Multi-Picture' option

1-1. For Quad Windows-

Choose your source in the 'source select' sub-menu

| | |
|---------------------|------------------------|
| Quad Window Options | Select an input option |
| Top-Left | |
| Top-Right | |
| Bottom-Left | |
| Bottom-Right | |

1-2. For PBP Top-Bottom

Choose your source in the 'source select' sub-menu

| | |
|---------------|-------------|
| PBP Options | Choose 1 |
| Top Source | Mini DP |
| | DisplayPort |
| Bottom Source | HDMI 1 |
| | HDMI 2 |

In PBP Top-Bottom, please adjust the screen resolution to 3840x1080 in order to display full-sized main-picture and sub-pictyre image.


1-3. For PBP Left-Right

Choose your source in the 'source select' sub-menu

| | |
|--------------|------------------------|
| PBP Options | Choose 1 |
| Left Source | Mini DP DisplayPort |
| Right Source | HDMI 1 HDMI 2 |

In PBP Left-Right, please adjust the screen resolution to 1920 x2160 in order to display full-sized main-picture and sub-picture image.

Main-picture Sub-picture



2. PIP

Under the PIP options choose which function you would like to adjust:

| |
|--------------|
| PIP Position |
| PIP Size |
| PIP Swap |

2-1. PIP Position

Choose one to adjust the smaller screen's position:

PIP H. Position adjusts the horizontal position of the smaller screen on a range from 0-100, with 0 starting from the left position of the screen and 100 starting from the right position of the screen.

PIP V. Position adjusts the vertical position of the smaller screen on a range from 0-100, with 0 starting from the bottom side of the screen and 100 starting from the top side of the screen.

2-2. PIP Size

You can adjust the size of the smaller window by pressing the up and down arrows, with a range of 0-100

2-3. PIP Swap

Press PIP Swap to change the image source of the smaller screen with the larger screen when the PIP function is selected

To deactivate any "multi-picture" mode, simply go to the "multi-picture" option and select the same mode again to reset your monitor back to normal.

Dual Color: The monitor comes with a dual color engine to display two different color setting in PIP or PBP mode. You can set different color presets in both the main picture and the sub-picture.

Step 1: Active your OSD

Step 2: Select the " Setup Menu"


Step 3: Select the "Multi-Picture " menu

Step 4: Selcet the" PBP Left-Right " menu or " PIP" menu


Step 5: Select the "Dual color"

Under the Dual Color sub menu choice which color you would like to display.

Main-picture Sub-picture



Dual color menu



Blue light filter

Shortcuts key for Low Blue Light

Press the #5 key to immediately activate the Low Blue Light function (w/signal)

Note: Viewing computer screens for extended periods of time may cause eye irritation and discomfort. To reduce these effects, it is recommended to take periodic breaks from viewing to allow the eyes to relax.

Calculating Breaks

When viewing the monitor for extended periods, it is recommended to take periodic breaks from viewing. Short breaks of at least 5 minutes are recommended after 1 -2 hour of continuous viewing. Taking shorter, more frequent breaks are generally more beneficial than longer, less frequent breaks.

Looking at distance objects

While taking breaks, users can further reduce eye strain and dryness by focusing on objects that are further away from them.

- **Eye Exercises**

Eye exercises can help minimize eye strain. Slowly roll your eyes to the left, right, up, down and repeat as needed.

- **Neck Exercises**

Neck exercises can also help minimize eye strain. Relax your arms to let them hang at your sides, bend forward slightly to stretch the neck, turn your head to the right and to the left and repeat as needed.

4-4. Advanced Settings for Gamers

These settings have been explained in the OSD menu section above. Their functional use and instructions on setup are below.

1. Low Input Lag

Step 1: Activate your OSD

Step 2: Select the “Manual Image Adjust” menu

Step 3: Select the “Advanced Image Adjust” menu

Step 4: Select Low Input Lag

Under the low input lag submenu, you can select the appropriate speed for your desired use from the two options

| |
|------------|
| Off |
| Advanced |
| Ultra Fast |

If you would like turn the Low Input Lag function off, select “Off”

2. Black Stabilization

Step 1: Activate your OSD


Step 2: Select the “Manual Image Adjust” menu

Step 3: Select the “Advanced Image Adjust” menu

Step 4: Select “Black Stabilization”

You can adjust the setting by using the arrow buttons, selecting a number value from 1-10, with 1 being the darkest and 10 being the lightest selection setting.

4-5. Monitor Setting Management



The monitor power management menu options are highlighted above. The explanation for each option is listed below.

OSD Timeout

The OSD Timeout function, allows users to choose how long the OSD will reside on the screen after in-activity (number of seconds).

OSD Background

The OSD Background function allows users to turn off the OSD background while selecting and adjusting OSD settings.

Power Indicator

The power indicator is the light that displays whether the monitor is on or off.

Auto Power Off

Selecting Auto Power Off, allows the monitor to shut its power off after a certain amount of time.

Sleep

This setting allows users to adjust the time of inactivity before the monitor goes on a reduced power mode. The screen will be on 'sleep mode' during this time.

Eco Mode

Allows users to choose between various modes, based on power consumption.

DDC/CI (Display Data Channel Command Interface)

Activating this setting allows monitor control via the graphics card.

5. Specifications

| | | |
|------------|---------------|--|
| LCD | Type | TFT (Thin Film Transistor), Active Matrix 3840 x 2160 LCD, 0.18159mm x 0.18159mm pixel pitch |
| | Display Size | Metric: 80.005 cm Imperial: 31.5" (31.5" viewable) |
| | Color Filter | RGB vertical stripe |
| | Glass Surface | Anti-Glare |

| | | |
|---------------------|------------|--|
| Input Signal | Video Sync | TMDS digital (100ohms) f _h :15-135 KHz, f _v :24-75 Hz |
|---------------------|------------|--|

| | | |
|----------------------|------------------------|---|
| Compatibility | PC | Up to 3840 x 2160 Non-interlaced |
| | Macintosh ¹ | Power Macintosh up to 3840 x 2160 (Supported by limited graphic cards) |

| | | |
|-------------------------------|-------------|--|
| Resolution² | Recommended | 3840 x 2160 @ 60 Hz |
| | Supported | 3840 x 2160 @ 30 Hz 3840 x 1080 @ 60 Hz 2560 x 1440 @ 60 Hz 1920 x 2160 @ 60 Hz 1920 x 1080 @ 60 Hz 1680 x 1050 @ 60 Hz 1440 x 900 @ 60 Hz 1280 x 1024 @ 60, 75 Hz 720 x 400 @ 70 Hz |

| | | |
|----------------------------------|---------------|-------------------------------------|
| Power Adaptor³ | Input Voltage | 100-240 VAC, 50/60 Hz (auto switch) |
|----------------------------------|---------------|-------------------------------------|

| | | |
|---------------------|-----------|--|
| Display area | Full Scan | 697.3056mm(H) x 392.2344mm(V) 27.45"(H) x 15.44"(V) |
|---------------------|-----------|--|

| | | |
|-----------------------------|-------------|---|
| Operating conditions | Temperature | +32 °F to +104 °F (0 °C to +40 °C) |
| | Humidity | 20% to 90% (non-condensing) |
| | Altitude | To 16404 feet |
| Storage conditions | Temperature | -4 °F to +140 °F (-20 °C to +60 °C) |
| | Humidity | 5% to 90% (non-condensing) |
| | Altitude | To 40,000 feet |
| Dimensions | Physical | 713.60 mm (W) x 636.08 mm (H) x 265.33 mm (D) 28.09 " (W) x 25.04 " (H) x 10.45" (D) |

| | | | | | |
|-------------------|--------------------|---------------------------------|----------------------------------|-----------------|---------------------------------------|
| Wall Mount | Max Loading | Hole pattern (W x H; mm) | Interface Pad (W x H x D) | Pad Hole | Screw Q'ty & Specification |
| | 14kg | 100mm x 100mm | 115 mm x 115 mm x 2.6 mm | Ø 5mm | 4 piece M4 x 10mm |

| | | |
|---------------------------|-----------------|--------------------------|
| Weight | Physical | 22.79 lb (10.33kg) |
| Power saving modes | On ⁴ | 51W (Typical) (Blue LED) |
| | Off | <0.3W |

- ¹ Macintosh computers may require a ViewSonic® Macintosh adapter. To order an adapter, contact ViewSonic.
- ² Do not set the graphics card in your computer to exceed these timing mode; doing so may result in permanent damage to the display.
- ³ Please use the power adaptor from ViewSonic® or authorized source only.
- ⁴ The test condition follows EEI standard

6. Troubleshooting

No power

- Make sure the power button (or switch) is ON.
- Make sure the A/C power cord is securely connected to the display.
- Plug another electrical device (like a radio) into the power outlet to verify that the outlet is supplying proper voltage.

Power is ON but no screen image

- Make sure the video cable supplied with the display is properly secured to the video output port on the back of the computer. If the other end of the video cable is not attached permanently to the display, properly secure it to the display.
- Adjust brightness and contrast.
- If you are using an Macintosh older than G3, you need a Macintosh adapt

Wrong or abnormal colors

- If any colors (red, green, or blue) are missing, check the video cable to make sure it is securely connected. Loose or broken pins in the cable connector could cause an improper connection.
- Connect the display to another computer.
- If you have an older graphics card, contact ViewSonic® for a non-DDC adapter.

Control buttons do not work

- Press only one button at a time.

7. Cleaning and Maintenance

Safe Cleaning Practices

- Make sure the display is turned off.
- Never spray or pour any liquid directly onto the screen or case.

To clean the screen:

1. Wipe the screen with a clean, soft, lint-free cloth. This removes dust and other particles.
2. If the screen is still not clean, apply a small amount of non-ammonia, non-alcohol based glass cleaner onto a clean, soft, lint-free cloth, and wipe the screen.


To clean the case:

1. Use a soft, dry cloth.
2. If the case is still not clean, apply a small amount of a non-ammonia, non-alcohol based, mild non-abrasive detergent onto a clean, soft, lint-free cloth, then wipe the surface.


Disclaimer

- ViewSonic® does not recommend the use of any ammonia or alcohol-based cleaners on the display screen or case. Some chemical cleaners have been reported to damage the screen and/or case of the display.
- ViewSonic will not be liable for damage resulting from use of any ammonia or alcoholbased cleaners.

Caution:



Handle the monitor on the edges only.



Clean with water on a soft cotton cloth only.

8. Compliance Information

NOTE: This section addresses all connected requirements and statements regarding regulations. Confirmed corresponding applications shall refer to nameplate labels and relevant markings on unit.

8-1. FCC Compliance Statement

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

8-2. Industry Canada Statement

CAN ICES-3 (B)/NMB-3(B)

8-3. CE Conformity for European Countries

CE The device complies with the EMC Directive 2014/30/EU and Low Voltage Directive 2014/35/EU.

Following information is only for EU-member states:

The mark shown to the right is in compliance with the Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE). The mark indicates the requirement NOT to dispose the equipment as unsorted municipal waste, but use the return and collection systems according to local law.



8-4. Declaration of RoHS2 Compliance

This product has been designed and manufactured in compliance with Directive 2011/65/EU of the European Parliament and the Council on restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS2 Directive) and is deemed to comply with the maximum concentration values issued by the European Technical Adaptation Committee (TAC) as shown below:

| Substance | Proposed Maximum Concentration | Actual Concentration |
|---|--------------------------------|----------------------|
| Lead (Pb) | 0.1% | < 0.1% |
| Mercury (Hg) | 0.1% | < 0.1% |
| Cadmium (Cd) | 0.01% | < 0.01% |
| Hexavalent Chromium (Cr ⁶⁺) | 0.1% | < 0.1% |
| Polybrominated biphenyls (PBB) | 0.1% | < 0.1% |
| Polybrominated diphenyl ethers (PBDE) | 0.1% | < 0.1% |

Certain components of products as stated above are exempted under the Annex III of the RoHS2 Directives as noted below:

Examples of exempted components are:

1. Mercury in cold cathode fluorescent lamps and external electrode fluorescent lamps (CCFL and EEFL) for special purposes not exceeding (per lamp):
 - (1) Short length (≤ 500 mm): maximum 3.5 mg per lamp.
 - (2) Medium length (> 500 mm and $\leq 1,500$ mm): maximum 5 mg per lamp.
 - (3) Long length ($> 1,500$ mm): maximum 13 mg per lamp.
2. Lead in glass of cathode ray tubes.
3. Lead in glass of fluorescent tubes not exceeding 0.2% by weight.
4. Lead as an alloying element in aluminium containing up to 0.4% lead by weight.
5. Copper alloy containing up to 4% lead by weight.
6. Lead in high melting temperature type solders (i.e. lead-based alloys containing 85% by weight or more lead).
7. Electrical and electronic components containing lead in a glass or ceramic other than dielectric ceramic in capacitors, e.g. piezo-electronic devices, or in a glass or ceramic matrix compound.

8-5. Indian Restriction of Hazardous Substances

Restriction on Hazardous Substances statement (India) This product complies with the “India E-waste Rule 2011” and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

8-6. Product Disposal at End of Product Life

ViewSonic respects the environment and is committed to working and living green. Thank you for being part of Smarter, Greener Computing.

Please visit ViewSonic website to learn more.

USA & Canada:

<http://www.viewsonic.com/company/green/recycle-program/>

Europe: <http://www.viewsoniceurope.com/eu/support/call-desk/>

Taiwan: <http://recycle.epa.gov.tw/recycle/index2.aspx>

9. Copyright Information

Copyright ©ViewSonic® Corporation, 2017. All rights reserved.

Macintosh and Power Macintosh are registered trademarks of Apple Inc.

Microsoft, Windows, and the Windows logo are registered trademarks of Microsoft Corporation in the United States and other countries.

ViewSonic, the three birds logo, OnView, ViewMatch, and ViewMeter are registered trademarks of ViewSonic Corporation.

VESA is a registered trademark of the Video Electronics Standards Association. DPMS, DisplayPort, and DDC are trademarks of VESA.

ENERGY STAR® is a registered trademark of the U.S. Environmental Protection Agency (EPA).

As an ENERGY STAR® partner, ViewSonic Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

Disclaimer: ViewSonic Corporation shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from furnishing this material, or the performance or use of this product.

In the interest of continuing product improvement, ViewSonic Corporation reserves the right to change product specifications without notice. Information in this document may change without notice.

No part of this document may be copied, reproduced, or transmitted by any means, for any purpose without prior written permission from ViewSonic Corporation.

10. Service Information

Product Registration

Thank you for purchasing a ViewSonic product! Registering activates your product's standard Limited Warranty and entitles you to receive new product updates and information if desired.

Please complete this form to register your new product, then mail/fax to ViewSonic using the information provided on the following page. Items marked with an asterisk (*) are required.

First Name* (given name) _____

Last Name* (family name) _____

Email Address* _____

Street Address* (line 1) _____

Street Address* (line 2) _____

City/Country* _____ State/Province* _____

Zip code/Postal code* _____ Country* _____

Phone Number* _____ Date Purchased* _____

Product Type* _____ Model Number* _____

Serial Number* _____

Operating System _____

YES NO | Check "YES" to receive email communication from ViewSonic, including exclusive promotional offers.

At ViewSonic we respect your privacy. ViewSonic does not sell its customer lists or similar information to third parties.

*Product registration available in selected countries only



Customer Service

For technical support or product service, see the table below or contact your reseller.

NOTE: You will need the product serial number.

| Asia pacific | | | |
|--|--|---|--------------------------------|
| Country/ Region | Website | T= Telephone C = CHAT ONLINE | Email |
| ViewSonic Corporation | http://www.viewsonic.com.tw/ | T= 886 2 2246 3456 F= 886 2 2249 1751 Toll Free= 0800-899880 | service@tw.viewsonic.com |
| China | www.viewsonic.com.cn | T= 4008 988 588 | service.cn@cn.viewsonic.com |
| Hong Kong | www.hk.viewsonic.com | T= 852 3102 2900 | service@hk.viewsonic.com |
| Macau | www.hk.viewsonic.com | T= 853 2840 3687 | service@hk.viewsonic.com |
| Japan | www.viewsonicjapan.co.jp | T= 0120 341 329 | service@jp.viewsonic.com |
| Korea | ap.viewsonic.com/kr/ | T= 080 333 2131 | service@kr.viewsonic.com |
| India | www.in.viewsonic.com | T= 1800 419 0959 | service@in.viewsonic.com |
| Singapore/ Malaysia/ Thailand | www.ap.viewsonic.com | T= 65 6461 6044 | service@sg.viewsonic.com |
| Europe | | | |
| Europe | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | |
| Arabia | ap.viewsonic.com/me/ | | اتصل بالبايع المحلي |
| България | www.viewsoinceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_bg@viewsoniceurope.com |
| Hrvatska | www.viewsoinceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_hr@viewsoniceurope.com |
| Česká Republika | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_cz@viewsoniceurope.com |
| Nederland | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_nl@viewsoniceurope.com |
| Suomi | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_fi@viewsoniceurope.com |
| France et autres pays francophones en Europe | www.viewsoniceurope.com/fr/ | www.viewsoniceurope.com/fr/support/call-desk/ | service_fr@viewsoniceurope.com |
| Canada | www.viewsonic.com | T (Numéro vert)= 1-866-463-4775 | service.ca@viewsonic.com |

| | | | |
|---|--|---|---------------------------------|
| Suisse | www.viewsoniceurope.com/de/ | www.viewsoniceurope.com/de/support/call-desk/ | service_ch@viewsoniceurope.com |
| Belgique (Français) | www.viewsoniceurope.com/fr/ | www.viewsoniceurope.com/fr/support/call-desk/ | service_be@viewsoniceurope.com |
| Luxembourg (Français) | www.viewsoniceurope.com/fr/ | www.viewsoniceurope.com/fr/support/call-desk/ | service_lu@viewsoniceurope.com |
| Deutschland | www.viewsoniceurope.com/de/ | www.viewsoniceurope.com/de/support/call-desk/ | service_deu@viewsoniceurope.com |
| Österreich | www.viewsoniceurope.com/de/ | www.viewsoniceurope.com/de/support/call-desk/ | service_at@viewsoniceurope.com |
| Schweiz (Deutsch) | www.viewsoniceurope.com/de/ | www.viewsoniceurope.com/de/support/call-desk/ | service_ch@viewsoniceurope.com |
| Ελλάδα | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_gr@viewsoniceurope.com |
| Magyar Köztársaság | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_hu@viewsoniceurope.com |
| Italia e altri paesi di lingua italiana in Europa | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_it@viewsoniceurope.com |
| Spain | www.viewsoniceurope.com/es/ | www.viewsoniceurope.com/es/support/call-desk/ | service_es@viewsoniceurope.com |
| Latinoamérica (México) | www.viewsonic.com/la/ | T= 001-8882328722 | soporte@viewsonic.com |
| Italia e altri paesi di lingua italiana in Europa | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_it@viewsoniceurope.com |
| Polska i inne kraje Europy Centralnej | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_pl@viewsoniceurope.com |
| Portugal | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_pt@viewsoniceurope.com |
| România | www.viewsoinceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_ro@viewsoniceurope.com |
| Россия | www.viewsoniceurope.com/ru/ | www.viewsoniceurope.com/ru/support/call-desk/ | service_ru@viewsoniceurope.com |
| Беларусь (Русский) | www.viewsoniceurope.com/ru/ | www.viewsoniceurope.com/ru/support/call-desk/ | service_br@viewsoniceurope.com |
| Латвия (Русский) | www.viewsoniceurope.com/ru/ | www.viewsoniceurope.com/ru/support/call-desk/ | service_lv@viewsoniceurope.com |
| Srbija | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_rs@viewsoniceurope.com |
| Slovensko | www.viewsoinceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_sk@viewsoniceurope.com |
| Slovenija | www.viewsoinceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_si@viewsoniceurope.com |
| Sverige | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_se@viewsoniceurope.com |

| | | | |
|--|---|---|--|
| Türkiye | http://www.viewsoniceurope.com/tr/ | www.viewsoniceurope.com/tr/support/call-desk/ | service_tr@viewsoniceurope.com |
| Україна | www.viewsoniceurope.com | http://www.viewsoniceurope.com/eu/support/call-desk/ | service_ua@viewsoniceurope.com |
| America | | | |
| Australia New Zealand | www.viewsonic.com.au | AUS= 1800 880 818 NZ= 0800 008 822 | service@au.viewsonic.com |
| Canada | www.viewsonic.com | T= 1-866-463-4775 | service.ca@viewsonic.com |
| Latin America (Argentina) | www.viewsonic.com/la/ | C= http://www.viewsonic.com/la/soporte/servicio-tecnico | soporte@viewsonic.com |
| Latin America (Chile) | www.viewsonic.com/la/ | C= http://www.viewsonic.com/la/soporte/servicio-tecnico | soporte@viewsonic.com |
| Latin America (Columbia) | www.viewsonic.com/la/ | C= http://www.viewsonic.com/la/soporte/servicio-tecnico | soporte@viewsonic.com |
| Latin America (Mexico) | www.viewsonic.com/la/ | C= http://www.viewsonic.com/la/soporte/servicio-tecnico | soporte@viewsonic.com |
| Nexus Hightech Solutions, Cincinnati #40 Desp. 1 Col. De los Deportes Mexico D.F. Tel: 55) 6547-6454 55)6547-6484 Other places please refer to http://www.viewsonic.com/la/soporte/servicio-tecnico#mexico | | | |
| Latin America (Peru) | www.viewsonic.com/la/ | C= http://www.viewsonic.com/la/soporte/servicio-tecnico | soporte@viewsonic.com |
| Middle East | ap.viewsonic.com/me/ | Contact your reseller | service@ap.viewsonic.com |
| Puerto Rico & Virgin Islands | www.viewsonic.com | T= 1-800-688-6688 (English) C= http://www.viewsonic.com/la/soporte/servicio-tecnico | service.us@viewsonic.com soporte@viewsonic.com |
| South Africa | ap.viewsonic.com/za/ | Contact your reseller | service@ap.viewsonic.com |
| United States | www.viewsonic.com | T= 1-800-688-6688 | service.us@viewsonic.com |

Limited Warranty

ViewSonic® Display

What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, and as your sole remedy, repair or replace the product with a similar product. Replacement Product or parts may include remanufactured or refurbished parts or components. The repair or replacement unit or parts or components will be covered by the balance of the time remaining on the customer's original limited warranty and the warranty period will not be extended. ViewSonic provides no warranty for any third-party software whether included with the product or installed by the customer, installation of any unauthorized hardware parts or components (e.g. Projector Lamps). (Please refer to: "What the warranty does not cover" section)

How long the warranty is effective:

ViewSonic displays are warranted for between 1 and 3 years, depending on your country of purchase, for all parts including the light source and for all labour from the date of the first consumer purchase

Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

What the warranty excludes and does not cover:

Any product on which the serial number has been defaced, modified or removed.

Damage, deterioration or malfunction resulting from:

1. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
2. Repair or attempted repair by anyone not authorized by ViewSonic.
3. Damage to or loss of any programs, data or removable storage media.
4. Software or data loss occurring during repair or replacement.
5. Any damage of the product due to shipment.
6. Removal or installation of the product.
7. Causes external to the product, such as electric power fluctuations or failure.
8. Use of supplies or parts not meeting ViewSonic's specifications.
9. Normal wear and tear.
10. Failure of owner to perform periodic product maintenance as stated in User Guide, such as cleaning of user-cleanable projector filters.
11. Any other cause which does not relate to a product defect.
12. Damage caused by static (non-moving) images displayed for lengthy periods of time (also referred to as image burn-in).
13. Software - Any third-party software included with the product or installed by the customer.

14. Hardware/Accessories/Parts/Components - Installation of any unauthorized hardware, accessories, consumable parts or components (e.g. Projector Lamps).
15. Damage to, or abuse of, the coating on the surface of the display through inappropriate cleaning as described in product User Guide.
16. Removal, installation, and set-up service charges, including wall-mounting of product.

How to get service:

1. For information about receiving service under warranty, contact ViewSonic Customer Support (Please refer to Customer Support page). You will need to provide your product's serial number.
2. To obtain warranty service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
3. Take or ship the product freight prepaid in the original container to an authorized ViewSonic service center or ViewSonic.
4. For additional information or the name of the nearest ViewSonic service center, contact ViewSonic.

Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

Exclusion of damages:

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

1. Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
2. Any other damages, whether incidental, consequential or otherwise.
3. Any claim against the customer by any other party.
4. Repair or attempted repair by anyone not authorized by ViewSonic.

Effect of state law:

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

Sales outside the U.S.A. and Canada:

For warranty information and service on ViewSonic products sold outside of the U.S.A. and Canada, contact ViewSonic or your local ViewSonic dealer.

The warranty period for this product in mainland China (Hong Kong, Macao and Taiwan Excluded) is subject to the terms and conditions of the Maintenance Guarantee Card.

For users in Europe and Russia, full details of warranty provided can be found in www.viewsoniceurope.com under Support/Warranty Information.

Mexico Limited Warranty

ViewSonic® Display

What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship, under normal use, during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, repair or replace the product with a like product. Replacement product or parts may include remanufactured or refurbished parts or components & accessories.

How long the warranty is effective:

ViewSonic LCD displays are warranted for between 1 and 3 years, depending on your country of purchase, for all parts including the light source and for all labour from the date of the first consumer purchase

Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

What the warranty does not cover:

1. Any product on which the serial number has been defaced, modified or removed.
2. Damage, deterioration or malfunction resulting from:
 - a. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, unauthorized attempted repair, or failure to follow instructions supplied with the product.
 - b. Causes external to the product, such as electrical power fluctuations or failure.
 - c. Use of supplies or parts not meeting ViewSonic's specifications.
 - d. Normal wear and tear.
 - e. Any other cause which does not relate to a product defect.
3. Any product exhibiting a condition commonly known as "image burn-in" which results when a static image is displayed on the product for an extended period of time.
4. Removal, installation, insurance, and set-up service charges.

How to get service:

For information about receiving service under warranty, contact ViewSonic Customer Support (Please refer to the attached Customer Support page). You will need to provide your product's serial number, so please record the product information in the space provided below on your purchase for your future use. Please retain your receipt of proof of purchase to support your warranty claim.

For Your Records

Product Name: _____ Model Number: _____

Document Number: _____ Serial Number: _____

Purchase Date: _____ Extended Warranty Purchase? __ (Y/N)

If so, what date does warranty expire? _____

1. To obtain warranty service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
2. Take or ship the product in the original container packaging to an authorized ViewSonic service center.
3. Round trip transportation costs for in-warranty products will be paid by ViewSonic.

Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

Exclusion of damages:

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

1. Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
2. Any other damages, whether incidental, consequential or otherwise.
3. Any claim against the customer by any other party.
4. Repair or attempted repair by anyone not authorized by ViewSonic.

| | |
|---|---|
| Contact Information for Sales & Authorized Service (Centro Autorizado de Servicio) within Mexico: | |
| Name, address, of manufacturer and importers: México, Av. de la Palma #8 Piso 2 Despacho 203, Corporativo Interpalmas, Col. San Fernando Huixquilucan, Estado de México Tel: (55) 3605-1099 http://www.viewsonic.com/la/soporte/index.htm | |
| NÚMERO GRATIS DE ASISTENCIA TÉCNICA PARA TODO MÉXICO: 001.866.823.2004 | |
| Hermosillo: Distribuciones y Servicios Computacionales SA de CV. Calle Juarez 284 local 2 Col. Bugambilias C.P: 83140 Tel: 01-66-22-14-9005 E-Mail: disc2@hmo.megared.net.mx | Villahermosa: Compumantenimietnos Garantizados, S.A. de C.V. AV. GREGORIO MENDEZ #1504 COL, FLORIDA C.P. 86040 Tel: 01 (993) 3 52 00 47 / 3522074 / 3 52 20 09 E-Mail: compumantenimientos@prodigy.net.mx |
| Puebla, Pue. (Matriz): RENTA Y DATOS, S.A. DE C.V. Domicilio: 29 SUR 721 COL. LA PAZ 72160 PUEBLA, PUE. Tel: 01(52).222.891.55.77 CON 10 LINEAS E-Mail: datos@puebla.megared.net.mx | Veracruz, Ver.: CONEXION Y DESARROLLO, S.A DE C.V. Av. Americas # 419 ENTRE PINZÓN Y ALVARADO Fracc. Reforma C.P. 91919 Tel: 01-22-91-00-31-67 E-Mail: gacosta@qplus.com.mx |
| Chihuahua Soluciones Globales en Computación C. Magisterio # 3321 Col. Magisterial Chihuahua, Chih. Tel: 4136954 E-Mail: Cefeo@soluglobales.com | Cuernavaca Compusupport de Cuernavaca SA de CV Francisco Leyva # 178 Col. Miguel Hidalgo C.P. 62040, Cuernavaca Morelos Tel: 01 777 3180579 / 01 777 3124014 E-Mail: aquevedo@compusupportcva.com |
| Distrito Federal: QPLUS, S.A. de C.V. Av. Coyoacán 931 Col. Del Valle 03100, México, D.F. Tel: 01(52)55-50-00-27-35 E-Mail : gacosta@qplus.com.mx | Guadalajara, Jal.: SERVICRECE, S.A. de C.V. Av. Niños Héroes # 2281 Col. Arcos Sur, Sector Juárez 44170, Guadalajara, Jalisco Tel: 01(52)33-36-15-15-43 E-Mail: mmiranda@servicrece.com |
| Guerrero Acapulco GS Computación (Grupo Sesicomp) Progreso #6-A, Colo Centro 39300 Acapulco, Guerrero Tel: 744-48-32627 | Monterrey: Global Product Services Mar Caribe # 1987, Esquina con Golfo Pérsico Fracc. Bernardo Reyes, CP 64280 Monterrey N.L. México Tel: 8129-5103 E-Mail: aydeem@gps1.com.mx |
| MERIDA: ELECTROSER Av Reforma No. 403Gx39 y 41 Mérida, Yucatán, México CP97000 Tel: (52) 999-925-1916 E-Mail: rrrb@sureste.com | Oaxaca, Oax.: CENTRO DE DISTRIBUCION Y SERVICIO, S.A. de C.V. Murguía # 708 P.A., Col. Centro, 68000, Oaxaca Tel: 01(52)95-15-15-22-22 Fax: 01(52)95-15-13-67-00 E-Mail: gpotai2001@hotmail.com |
| Tijuana: STD Av Ferrocarril Sonora #3780 L-C Col 20 de Noviembre Tijuana, Mexico | FOR USA SUPPORT: ViewSonic Corporation 381 Brea Canyon Road, Walnut, CA. 91789 USA Tel: 800-688-6688 (English); 866-323-8056 (Spanish); E-Mail: http://www.viewsonic.com |

LCD Mexico Warranty Term Template In UG

VSC_TEMP_2008



ViewSonic®